



Grandstream Networks, Inc.

GVC3220

Ultra HD Multimedia Conferencing System

User Guide



COPYRIGHT

©2022 Grandstream Networks, Inc. <https://www.grandstream.com>

All rights reserved. Information in this document is subject to change without notice. Reproduction or transmittal of the entire or any part, in any form or by any means, electronic or print, for any purpose without the express written permission of Grandstream Networks, Inc. is not permitted.

The latest electronic version of this guide is available for download here:

<https://www.grandstream.com/support>

Grandstream is a registered trademark and Grandstream logo is trademark of Grandstream Networks, Inc. in the United States, Europe, and other countries.

CAUTION

Changes or modifications to this product not expressly approved by Grandstream, or operation of this product in any way other than as detailed by this guide, could void your manufacturer warranty.

WARNING

Please do not use a different power adaptor with devices as it may cause damage to the products and void the manufacturer warranty.



CE Authentication



BE	BG	CZ	DK	DE	EE	IE	EL	LI
ES	FR	HR	IT	CY	LV	LT	LU	CH
HU	MT	NL	AT	PL	PT	RO	SI	TR
SK	FI	SE	NO	IS	UK	UK(NI)		

In the UK and EU member states, operation of 5150-5350 MHz is restricted to indoor use only.

Hereby, Grandstream Networks, Inc. declares that the radio equipment GVC3220 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<https://www.grandstream.com/support/resources/>

GNU GPL INFORMATION

GVC3220 firmware contains third-party software licensed under the GNU General Public License (GPL). Grandstream uses software under the specific terms of the GPL. Please see the GNU General Public License (GPL) for the exact terms and conditions of the license.

Grandstream GNU GPL related source code can be downloaded from Grandstream Web site from:

<https://www.grandstream.com/sites/default/files/Resources/gvc32xx-gpl.tar.gz>



Table of Contents

DOCUMENT PURPOSE	15
CHANGE LOG	16
Firmware Version 1.0.1.35	16
Firmware Version 1.0.1.27	16
Firmware Version 1.0.1.24	16
WELCOME	17
PRODUCT OVERVIEW	18
INSTALLING GVC3220	21
Equipment Package Content	21
Connecting GVC3220	21
Connecting GMD1208 to GVC3220	24
GETTING TO KNOW GVC3220	27
Remote Control	27
<i>Remote Control Keys and Touchpad</i>	27
<i>Capturing Screenshot Using the Remote Control</i>	30
<i>Using the Remote Control</i>	30
Using Mouse & Keyboard	31
Using the LED Indicator	31
Status Icons	32
Using the Onscreen Keyboard	34
<i>English Keyboard</i>	34
<i>Numbers and Symbols</i>	34
Home Screen	34
<i>GVC3220 Menu</i>	35
Screen Lock	37
System Configurations	37
<i>HDMI Settings</i>	38
<i>Site Name</i>	38
<i>Storage</i>	40



App & Application account.....	40
CONNECTING TO NETWORK AND DEVICES	42
Ethernet	42
<i>Using IPv4</i>	42
<i>Using IPv6</i>	44
WI-FI	44
<i>Turning Wi-Fi On/Off</i>	45
<i>Wireless Projection</i>	46
LLDP and VLAN Settings.....	46
802.1X Mode.....	48
Proxy.....	49
CAMERA	50
Preset.....	51
<i>Add Preset</i>	51
Camera Parameters Configurations	52
PERIPHERAL	54
External USB Device	54
<i>Using USB Mouse/Keyboard</i>	54
<i>Storage Device</i>	54
Microphone and Speaker.....	55
MAKING PHONE CALLS	57
Account	57
Dial Screen	57
<i>Dialing a Number Directly</i>	58
<i>Dialing BlueJeans/Zoom call</i>	59
<i>Redial</i>	60
<i>Dialing a Number via Contact</i>	60
<i>Dialing a Number via Call History</i>	60
<i>Direct IP Call</i>	60
<i>Paging/Intercom</i>	61
Contacts.....	61



<i>Add Contact/Group</i>	63
Answering a Call	65
Call Hold	66
Mute Local Audio	66
Call Recording	67
DND (Do Not Disturb)	67
Missed Call	68
Call Forward	68
Conference	68
<i>Device Layout</i>	68
<i>Initiating Conference</i>	69
<i>Answering an Incoming Call in Conference</i>	69
<i>Conference Management</i>	70
<i>Invite Members to Conference</i>	72
<i>Conference Control</i>	73
<i>Pause Conference</i>	74
<i>Conference Layout</i>	74
<i>Presentation Sharing</i>	76
<i>Web GUI Sharing</i>	77
<i>Participants List</i>	78
<i>Call Details</i>	79
<i>Conference Lock</i>	79
<i>Open DTMF</i>	80
<i>PIN Code</i>	80
<i>FECC - Camera Control in Conference</i>	81
<i>End Conference</i>	82
<i>Power Off During a Conference Call</i>	82
Schedule	83
<i>View Conference Details</i>	84
<i>Add Scheduled Conference</i>	86
<i>Edit Scheduled Conference</i>	87
Voicemail	88
Call Features	89



ADDITIONAL FUNCTIONS 91

Bluetooth	91
<i>Using Bluetooth Remote Control</i>	92
<i>Using Bluetooth Headset</i>	93
GVC Remote Client Application	93
Power Manager	96

APPLICATIONS 97

LDAP contacts	97
<i>LDAP Settings</i>	99
Call History	102
<i>Add Contact from Call History</i>	103
File Manager	103
<i>Browse Files</i>	103
<i>File Operations</i>	105
Recorder	108
Setup Wizard	109
Backup	114
<i>Backup Data</i>	114
<i>Restore Backup Data</i>	116
State Detection	116
Uninstall Application	119

GS MARKET 120

View Apps	120
Update Apps	121

IPVIDEOTALK 122

Instant Meetings	123
Meeting List	123
Call	123
IPVideoTalk Contacts	123
Notices	124
Settings	125
Join an IPVideoTalk Meeting	126
Busy Tone Responses	127
Manually Start IPVideoTalk Tip	127



Conference Control.....	128
<i>IPVideoTalk Meeting Operations</i>	128
Start Cloud Recording.....	130
GVC3220 WEB UI FEATURES.....	131
Accessing GVC3220 Web GUI.....	131
Share Screen (without login)	132
Saving Changes.....	133
Definitions	134
Toolbar	135
Call Page	135
Contacts Page	136
<i>Web GUI Contacts</i>	136
<i>Groups</i>	136
<i>Schedule</i>	137
<i>Call History</i>	138
Device Control Page	138
FACTORY RESET	140
Reset via LCD.....	140
Reset via Web UI	140
Reset via Reset Hole	141
EXPERIENCING GVC3220	142



Table of Tables

Table 1: GVC3220 Technical Specifications	18
Table 2: GVC3220 Package List	21
Table 3: GVC3220 Back Panel	23
Table 4: GVC3220 Remote Control Keys	27
Table 5: GVC3220 LED Indicator Status Descriptions	32
Table 6: GVC3220 Status Icons Descriptions	33
Table 7: GVC3220 LLDP Configuration Parameters.....	47
Table 8: GVC3220 802.1x Mode Parameters	49
Table 9: GVC3220 Camera Parameters	52
Table 10: GVC3220 Call Screen Bottom Menu Icons	70
Table 11: GVC3220 Conference Member Status Descriptions	72
Table 12: GVC3220 Add Conference Parameters	86
Table 13: GVC3220 Feature Code for SIP Account.....	89
Table 14: GVC3220 LDAP Settings Parameters.....	99
Table 15: GVC3220 Web Access	134

Table of Figures

Figure 1: GVC3220 Front Panel	21
Figure 2: GVC3220 Back Panel	22
Figure 3: GVC3220 Back Panel Connection Diagram	24
Figure 4: Wireless Microphone Disconnected	25
Figure 5: Wireless Microphone Connecting	25
Figure 6: GVC3220 Remote Control.....	27
Figure 7: GVC3220 Top Status Bar Dropdown Menu	32
Figure 8: Soft Keyboard - English Input Method	34
Figure 9: Soft Keyboard - Symbols and Numbers	34
Figure 10: GVC3220 Home Screen	35
Figure 11: Screen Lock Password	37
Figure 12: Settings – System.....	37
Figure 13: System - HDMI Settings	38
Figure 14: System - Site Name	38
Figure 15: System Storage	40
Figure 16: Available Apps List.....	40
Figure 17: Add Google Account	41



Figure 18: Ethernet Settings	42
Figure 19: IPv4 Settings - DHCP	43
Figure 20: IPv4 Settings - Static	43
Figure 21: IPv4 Settings - PPPoE	43
Figure 22: IPv6 Settings - DHCP	44
Figure 23: IPv6 Settings - Static	44
Figure 24: Network Settings.....	45
Figure 25: GVC3220 Add Wi-Fi Screen	45
Figure 26: Add Network.....	45
Figure 27: Wireless Projection	46
Figure 28: LLDP/VLAN Settings	47
Figure 29: Network Advanced Settings.....	48
Figure 30: 802.1X - EAP-MD5	48
Figure 31: 802.1X - EAP-TLS	48
Figure 32: 802.1X - EAP-PEAP	48
Figure 33: Proxy.....	49
Figure 34: Proxy Settings.....	49
Figure 35: GVC3220 Camera Screen.....	50
Figure 36: GVC3220 Add Preset Screen	51
Figure 37: GVC3220 Camera Parameters Setting Screen.....	52
Figure 38: Storage Device	54
Figure 39: Browse Storage Device	55
Figure 40: Audio Calibration.....	56
Figure 41: GVC3220 IPVideoTalk Account	57
Figure 42: GVC3220 Call Screen	58
Figure 43: BlueJeans/Zoom Call Screen	59
Figure 44: Contacts.....	61
Figure 45: GVC3220 Contacts Screen	62
Figure 46: Contacts - Local Groups	62
Figure 47: contact delete screen.....	63
Figure 48: GVC3220 Add New Contact Screen.....	64
Figure 49: New Contact - More Fields	64
Figure 50: New Group.....	64
Figure 51: GVC3220 Single Incoming Call Screen.....	65
Figure 52: GVC3220 New Incoming Call Screen	65
Figure 53: Hold screen.....	66
Figure 54: Mute screen	66
Figure 55: Missed Call notification	68
Figure 56: Call Screen	69
Figure 57: GVC3220 3-Way Conference	70
Figure 58: GVC3220 Conference Control Screen	73
Figure 59: Conference Control Operations	74



Figure 60: Layout customization	74
Figure 61: Local Layouts	75
Figure 62: Cloud Layouts	75
Figure 63: GVC3220 3-Way Conference with Presentation	77
Figure 64: Enable Web GUI Screen sharing.....	77
Figure 65: Web GUI - Share your screen	78
Figure 66: Stop Web GUI Screen sharing	78
Figure 67: GVC3220 Participants List.....	79
Figure 68: GVC3220 Call Details Screen	79
Figure 69: Conference - Dial DTMF	80
Figure 70: Enter PIN Code to Lock Conference	80
Figure 71: FECC – Remote Camera Control	81
Figure 72: End Conference	82
Figure 73: Power Off	83
Figure 74: Power Off During a Call	83
Figure 75: GVC3220 Schedule Screen.....	83
Figure 76: GMS Google Kit not installed.....	84
Figure 77: “Over” Conference Details Screen.....	85
Figure 78: “Not Start” Conference Details Screen	85
Figure 79: GVC3220 Add Meeting Screen.....	86
Figure 80: Edit conference	87
Figure 81: Settings - Voicemail	88
Figure 82: Voicemail Access Number Prompt.....	88
Figure 83: Basic Settings - Bluetooth.....	91
Figure 84: Bluetooth Settings.....	91
Figure 85: GVC3220 Bluetooth – Open Discovery	92
Figure 86: Connecting a Bluetooth Headset	93
Figure 87: Status - Remote control	93
Figure 88: Remote Control Settings.....	94
Figure 89: GVC3220 Remote Control Application on Android Device	94
Figure 90: Send the GVC Remote apk using Bluetooth	95
Figure 91: QR Code for Remote Control App	95
Figure 92: Timeout Operation	96
Figure 93: Timeout Time	96
Figure 94: Screensaver Timeout.....	96
Figure 95: GVC3220 Applications	97
Figure 96: Applications - LDAP contacts.....	97
Figure 97: LDAP Contacts Interface	98
Figure 98: LDAP contacts - Batch Add	98
Figure 99: LDAP contacts - Settings	99
Figure 100: LDAP Settings Example in Web UI.....	101
Figure 101: GVC3220 Call History Screen	102



Figure 102: GVC3220 Call History Details.....	102
Figure 103: GVC3220 Add Contact Screen.....	103
Figure 104: Applications - File Manager.....	104
Figure 105: File Manager Folders.....	104
Figure 106: File Manger - Search.....	104
Figure 107: File Operations Panel.....	105
Figure 108: File Manager - Share File.....	105
Figure 109: File Manager - Rename File.....	106
Figure 110: File Manager - Properties.....	106
Figure 111: File Manager - Search.....	106
Figure 112: File Manager - New Folder.....	106
Figure 113: File Manager - Sort.....	107
Figure 114: File Manager - List/Icon View.....	107
Figure 115: Applications - Recorder.....	108
Figure 116: GVC3220 Recording Screen.....	108
Figure 117: Recorder App - Video Settings.....	108
Figure 118: Setup Wizard.....	109
Figure 119: Setup Wizard – start.....	109
Figure 120: Setup Wizard - Configuration Mode.....	109
Figure 121: Setup Wizard - Interface Detection.....	110
Figure 122: Setup Wizard – Ethernet.....	110
Figure 123: Setup Wizard - Static IP.....	111
Figure 124: Setup Wizard - Wi-Fi scan.....	111
Figure 125: Setup Wizard - GMD.....	111
Figure 126: Setup Wizard - Account.....	112
Figure 127: Setup Wizard - Remote Control.....	112
Figure 128: Setup Wizard - Remote Control Settings.....	113
Figure 129: Setup Wizard – IPVideoTalk.....	113
Figure 130: Setup Wizard – End.....	114
Figure 131: File Manager - Backups.....	114
Figure 132: New Backup.....	115
Figure 133: GVC3220 Automatic Backup Screen.....	115
Figure 134: GVC3220 Restore Backup Data Screen.....	116
Figure 135: Applications – State Detection.....	116
Figure 136: Interface Detection.....	117
Figure 137: Network/Account Detection.....	117
Figure 138: Audio Detection.....	117
Figure 139: System - Apps.....	118
Figure 140: Reset app preferences.....	119
Figure 141: Delete App.....	119
Figure 142: GVC3220 GS Market.....	120
Figure 143: GMS Installation.....	121



Figure 144: GVC3220 IPVideoTalk Application.....	122
Figure 145: IPVideoTalk - Contacts	123
Figure 146: IPVideoTalk - Notices.....	124
Figure 147: Notices - Messages	124
Figure 148: Notices - Details.....	125
Figure 149: IPVideoTalk Account Settings	125
Figure 150: Current Plan used and its expiration time.....	126
Figure 151: IPVideoTalk Dialing Page	127
Figure 152: Manually start Scheduled Meeting	128
Figure 153: Participants list.....	129
Figure 154: Lower hand of one participant	129
Figure 155 : Server Recording.....	130
Figure 156 : IPVideoTalk Recordings.....	130
Figure 157: IP Address from the display device.....	131
Figure 158: GVC3220 Web GUI - Login	131
Figure 3: Share Screen – Enter the code	132
Figure 3: Share Screen Code	132
Figure 3: Share Screen – Select the screen to share.....	133
Figure 159: Reboot is mandatory.....	133
Figure 160: GVC3220 Web UI Tool Bar	135
Figure 161: GVC3220 Web UI - Call.....	135
Figure 162: GVC3220 Web UI - Contacts.....	136
Figure 163: GVC3220 Web UI - Groups	137
Figure 164: GVC3220 Web Page - Schedule	137
Figure 165: GVC3220 Web UI - Call History	138
Figure 166: Web GUI - Preset Control.....	139
Figure 167: GVC3220 Web UI - Camera Control	139
Figure 168: Factory Reset via LCD.....	140
Figure 169: GVC3220 Web UI - Factory Reset	140
Figure 170: GVC3220 Web UI - Factory Reset Confirmation.....	141



DOCUMENT PURPOSE

This User Guide describes the basic concept and tasks necessary to use and configure your GVC3220.

This document covers the topics of device installation, making basic conference calls and using basic call features.

To learn the advanced features and configurations, please visit <https://www.grandstream.com/support> to download the latest "GVC3220 Administration Guide".

This guide covers following topics:

- [Product Overview](#)
- [Installing GVC3220](#)
- [Getting to know GVC3220](#)
- [Connecting to Network and Devices](#)
- [Camera](#)
- [Peripheral](#)
- [Making Phone Calls](#)
- [Additional Functions](#)
- [Applications](#)
- [GS Market](#)
- [IPVideoTalk](#)
- [GVC3220 Web UI Features](#)
- [Factory Reset](#)
- [Experiencing GVC3220](#)



CHANGE LOG

This section documents significant changes from previous versions of GVC3220 user manuals. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

Firmware Version 1.0.1.35

- Added Screen sharing when web is not logged in. [Share Screen (without login)]
- Added IPVT Layout function. [Conference Layout]
- Added IPVT FECC function. [FECC - Camera Control in Conference]
- Added USB pairing of GMD. [Connecting GMD1208 to GVC3220]
- Added GMD acoustic echo cancellation feature. [Microphone and Speaker]
- Added ability to use camera zoom and PTZ when using Teams or Zoom application. [Using the Remote Control]

Firmware Version 1.0.1.27

- Added camera PTZ/zoom functionalities in 3rd party apps such as Microsoft Teams and Zoom. [Using the Remote Control]
- Improved device performance of 3rd party meetings such as system stability and echo issues.

Firmware Version 1.0.1.24

- This is the initial version.



WELCOME

Thank you for purchasing Grandstream GVC3220 Ultra HD Multimedia Conferencing System. This document introduces the LCD settings, and basic configuration of the GVC3220. To learn Web GUI settings and advanced configuration, please visit <http://www.grandstream.com/support> to download the latest "GVC3220 Admin Guide".

The GVC3220 is a revolutionary video conferencing system that provides an interactive and immersive video conferencing environment to increase collaboration and productivity. This SIP-based GVC3220 allows the user to connect their video conferencing solutions with any 3rd-party SIP or H.323 video conferencing platform. Additionally, since the GVC3220 is based on an Android 9.0 operating system. Users will elevate their experience with its 4K Ultra-HD video, up to 5-way 1080P video conferences, screen-sharing capabilities, Integrated Wi-Fi, Bluetooth 5.0 + EDR and more.

The GVC series supports Grandstream's IPVideoTalk Video and Web Conferencing platform. This paid subscription-based service allows users to turn any meeting hosted on any GVC device into an online meeting that can be joined seamlessly from a web browser or GVC. Turn any physical room into a virtual, online meeting place to offer your customers the tools they need to be successful, no matter where they are.

The GVC3220 eliminates the traditional barriers to video conferencing and sets a new bar for business-class video conferencing solutions by offering industry-leading flexibility, interoperability, system compatibility, application richness and ease of use.



PRODUCT OVERVIEW

Table 1: GVC3220 Technical Specifications

Specification	Description
Protocols/ Standards	SIP RFC3261, H.323,BFCP, TIP, RTP/RTCP, HTTP/HTTPS, ARP, ICMP, DNS (A record, SRV, NAPTR), DHCP, PPPoE, SSH, TFTP, NTP, STUN, SIMPLE,LLDP-MED, LDAP, TR-069, 802.1x, TLS, SRTP, TCP/IP/UDP, IPv6, OpenVPN®
MCU	Up to 5-way video conferencing with 1080p @30fps, and 9-way with 720p @30fps conference
Camera	1/2.5", 8 Megapixel CMOS, 4k 30fps or 1080p 60fps output
Lens	12x optical zoom,+/-30° tilt, +/-170° pan, 70.1°~7.4°(W) Field of View, 40.7°~4.2°(T) field of view
Network Interface	1× RJ45 10/ 100/ 1000 Mbps
Wi-Fi	Integrated dual-band 802.11 a/b/g/n/ac (2.4GHz & 5GHz), support Wireless Multimedia
Bluetooth	Integrated Bluetooth 5.0 + EDR
Video Outputs	1x HDMI 2.0 up to 4k 1x HDMI 1.4 up to 1080p
Video Input	1x HDMI 1.4a with resolution up to 1080P
Mic/Speaker	Support external Bluetooth or 2.4G microphone 1 built-in speaker.
Audio Input/Outputs	1x Line in/out 1x Media
Remote Control	Bluetooth and infrared remote control with multi-touch touchpad
Auxiliary Ports	1x USB 3.0 1x USB 2.0 1x SD 1x Reset
Voice Codecs	Support for G.711μ/a, G.722 (wide-band), iLBC, Opus , G.722.1, G.722.1C ,G729A/B, in-band and out-of-band DTMF (In audio, RFC2833, SIP INFO)
Video Codecs	H.264 BP/MP/HP Video resolution up to 4K, frame rate up to 30fps, bit rate up to 8Mbps
Portrait Video Resolutions	4K from 1Mbps to 8Mbps, 1080P from 1Mbps to 4Mbps, and 720P from 512Kbps to 2Mbps



Content Video Resolution	Input: 720P, 1080P (HDMI) Encoding: 800×600, 1024×768, 1280×1024, 1280×720, 1920×1080 Output: 720P, 1080P
Dual-Stream	BFCP, people video (up to 4K@30fps) + content video (up to 1080P@15fps)
Audio Features	AEC, ANS, AGC, PLC, CNG/VAD
Video Features	FEC, dynamic display layout, picture-in-picture, picture-outside-picture
Video Conferencing Service Platform	SIP, H.323, Grandstream IPVideoTalk, Bluejeans and Zoom
Telephony Features	Hold, mute, downloadable phone book (XML, LDAP), call waiting, call history, flexible dial plan, server redundancy & fail-over.
Sample Applications	Microsoft Teams, Zoom, YouTube, etc. API/SDK available for advanced custom application development
Application Deployment	Allow various Android operation system 9.0 compliant applications to be developed, downloaded, and run in the embedded device with provisioning control
QoS	Layer 2 QoS (802.1Q, 802.1p) and Layer 3 (ToS, DiffServ, MPLS) QoS
Security	User and administrator level passwords, MD5 and MD5-sess based authentication, 256-bit AES encrypted configuration file, TLS, 128/256-bit SRTP, HTTPS, 802.1x media access control
Multi-Language	English, German, Italian, French, Spanish, Portuguese, Russian, Chinese and more
Upgrade/ Provisioning	Firmware upgrade via TFTP / HTTP / HTTPS or local HTTP upload, mass provisioning using TR-069 or AES encrypted XML configuration file. Detect U disk /SD card system version upgrade automatically.
Power & Green Energy Efficiency	Universal power adapter: Input: 100~240Vac 50~60Hz Output: 48V/1.35A(64.8W)
Package Content	GVC3220 video conference system, GMD1208 wireless microphone, remote control, 4 AAA batteries, universal power supply, network cable (2 meters), HDMI cables (1x 5 meters, 2x 1.5 meters), lens cleaning cloth, bracket, quick installation guide
Temperature and Humidity	Operation: 0°C to 40°C Storage: -10°C to 60°C Humidity: 10% to 90% (Non-condensing)
Compliance	Broadsoft FCC: Part15 Class B; Part 15 Subpart C 15.247; Part 15 Subpart E 15.407; MPE.



CE: EN 55032; EN 55035; EN 61000-3-2; EN 61000-3-3; EN 62368-1; EN 301 489-1;
EN 301 489-17; EN 300 328; EN 301 893; EN 62311.
RCM: AS/NZS CISPR32; AS/NZS 4268; AS/NZS 62368.1. IC: ICES-003; RSS-GEN;
RSS-247; RSS-102(MPE).
HDMI/EAC/REACH/ROHS/WEEE

Safety Compliances

GVC3220 complies with FCC/CE and various safety standards. GVC3220 power adapter is compliant with the UL standard. Use the universal power adapter provided with the device package only. The manufacturer's warranty does not cover damages to the device caused by unsupported power adapters.

Warranty

If GVC3220 is purchased from a reseller, please contact the company where the device is purchased for replacement, repair, or refund. If the device is purchased directly from Grandstream, please contact Grandstream Support for an RMA (Return Materials Authorization) number before the product is returned. Grandstream reserves the right to remedy warranty policy without prior notification.



INSTALLING GVC3220

Equipment Package Content

GVC3220 package contains the following items:

Table 2: GVC3220 Package List

1x GVC3220 video conference system,	1x Universal Power Supply: - Power cord - Power adapter
1x GMD1208 wireless microphone,	
1x Remote Control,	Screws and anchors: - 2x Hand Screws - 3x PM3*8 Screws - 4x PA4.0*30 Screws - 4x Anchors
4x AAA batteries,	
1x network cable (2 meters),	
1x lens cleaning cloth,	
1x lens cover	
1x Wall Mount Bracket,	HDMI cables: - 1x 5 meters - 2x 1.5 meters
Quick Installation Guide	

Connecting GVC3220




Figure 1: GVC3220 Front Panel




Figure 2: GVC3220 Back Panel

Please connect GVC3220 according to the following procedures:

1. Connect the LAN port of the GVC3220 to the RJ-45 socket of a hub/switch or a router (LAN side of the router) using the Ethernet cable.
2. Connect the primary HDMI output port (marked with a blue highlight) of the GVC3220 to the HDMI port of the main display device (e.g., TV)
 - Using the HDMI cable. Connect the second HDMI output port if you have additional display devices.

Note: There are 2 HDMI output ports. The interface marked with a blue highlight is the primary interface to output primary video. Please make sure to follow the port order when connecting HDMI output ports. When there is only 1 HDMI output, it has to use the primary HDMI port. Connect the secondary HDMI output port only if you have additional display devices. GVC3220 will not work correctly if connecting the secondary HDMI output port without making sure primary HDMI output port is connected.
3. Connect the 48V DC output plug to the power jack on the GVC3220; plug the power adapter into an electrical outlet.
4. The display device (e.g., TV) will show the idle HOME screen with IP address on the top status bar.

5. Insert your SD card into the SD card slot. The recording files will be saved in SD card.
6. (Optional) Connect presentation device (e.g., a laptop) to the GVC3220 HDMI IN port for presentation purpose during conference call.
7. (Optional) Connect USB accessory (e.g., mouse, keyboard, USB flash drive and etc.) to the USB port.

Table 3: GVC3220 Back Panel

Name	Explanation
Line IN	Connect an external Microphone
Line OUT	Connect an external Speaker
HDMI Input Interface	Connect to an HDMI input device for presentation.
HDMI Output Interface	Connect the HDMI display devices. Note: There are 2 HDMI output ports. The interface marked with a blue highlight is the primary interface to output primary video. Please make sure to follow the port order when connecting HDMI output ports. When there is only 1 HDMI output, it has to use the primary HDMI port. Connect the secondary HDMI output port only if you have additional display devices. GVC3220 will not work correctly if connecting the secondary HDMI output port without making sure primary HDMI output port is connected.
SD Card Slot	Insert SD card to store call recordings and other necessary files.
USB Interface	Connect to USB device (storage, mouse, keyboard ...).
Network Interface	Connect to LAN port.
Power Interface	Connect to power adapter. The arrow indicator on the power adapter should face upwards when the power adapter is plugged in.
Factory Restore	When powering up GVC3220, keep pressing the button with a small pin for more than 10 seconds to restore to factory settings.

Note: For detailed instructions about installing GVC3220 on wall mount and etc., please refer to the GVC3220 Quick Installation Guide on www.grandstream.com.

A sample of GVC3220 back panel connection is shown below:




Figure 3: GVC3220 Back Panel Connection Diagram

Connecting GMD1208 to GVC3220

- **2.4G Mode:**

1. Switch the GMD1208 to 2.4G mode (switch on the back of the device).
2. Press and hold the MUTE button of GMD1208 for 3 seconds until the working indicator light is green and the mute light is blinking.
3. Bring GMD1208 close to the GVC3220.
4. Go to **"Settings → Basic → GMD Wireless Microphone"** page on GVC3220 local GUI and click "Search". The devices will finish pairing and connection automatically.



Figure 4: Wireless Microphone Disconnected




Figure 5: Wireless Microphone Connecting

- **BT Mode:**

1. Switch to BT mode. GMD1208 will enter pairing procedure automatically after bootup.
2. The Working Status Indicator flashing in blue meaning that GMD1208 is not paired yet.
3. When paired, Working Status Indicator will be solid blue.

- **USB Mode:**

1. Switch the GMD1208 to 2.4G mode (switch on the back of the device).
2. Then the GMD1208 will automatically pair with GVC3220 when connected via USB.

For more information about GMD1208, please refer to the GMD1208 product page in www.grandstream.com.



GETTING TO KNOW GVC3220

Remote Control

Remote Control Keys and Touchpad





Figure 6: GVC3220 Remote Control

Table 4: GVC3220 Remote Control Keys

Icon	Name	Explanation
1, 2, 3, 4...9	Digital Keys	Input number 1-9 and letters. The letter input using digital keys will not be displayed as letter, but it can be used to search for contacts in Call interface. For example, typing 5 (JKL), 6 (MNO), 4 (GHI), 6 (MNO) can look for John if it exists in GVC3220 contacts list.
	Camera	Switch to PTZ control mode during a call or in idle status.
	PIP	Switch screen layout in conference.

	Mute/DND	<ul style="list-style-type: none"> Mute GVC3220 in conference. Press the MUTE key to enable/disable DND mode when GVC3220 is in idle.
	Presentation	<ul style="list-style-type: none"> Enable/Disable presentation function to send presentation to all members in the conference. Enable/Disable presentation function to show presentation on displayed device which is connected to HDMI output 1 as projection when GVC3220 is in standby mode.
	Send/Answer/Add Party into Conference	<ul style="list-style-type: none"> Access the dial screen by default when GVC3220 is in idle mode. Enter phone number and press the key to dial out. Access the invite screen to add members in a conference. Press the key to bring out the backstage conference. Press the key to redial the last outgoing call.
	End Call/Remove Party from Conference	<ul style="list-style-type: none"> Delete members in conference. Hang up the conference.
	Backspace	<p>Press the key to delete input characters.</p>
	Navigation Keys: Up/Down/Left/Right	<ul style="list-style-type: none"> Press to adjust cursor movement. Control PTZ movement in camera mode or 3rd party apps (Teams, Zoom)
	OK	<ul style="list-style-type: none"> Press to confirm operations. Bring up the soft keypad when the cursor is in an input box.
	Power On/Off	<p>LCD prompt shows the following three options after pressing this key:</p> <ul style="list-style-type: none"> Switch GVC3220 into sleep mode. Power Off Reboot <p>When the power button is pressed second time, the pop-up window will be closed.</p>

	*/Record	<ul style="list-style-type: none"> • Input * in input field. • Used as "." when dialing direct IP call. For example, 192.168.40.5. • Start/stop recording in camera control mode. • Start/stop recording in a call.
	#/Details	<ul style="list-style-type: none"> • Input "#" in input field. • Used as ":" when dialing direct IP Call e.g., 192.168.40.5:5060. • Input "#" on dialing screen to use it as REDIAL key. • Display call details on call screen during a call.
	Shortcut Key: Red	Press each shortcut key for designated functions on different screen context.
	Shortcut Key: Yellow	
	Shortcut Key: Blue	
	Home	Press the key to go back to home screen.
	Menu	Press the key to view more options.
	Back	Press the key to go back to the previous screen or exit the current screen.
	Volume Down	Turn down the device volume.
	Volume Up	Turn up the device volume.
	Zoom In	Zoom in screen or adjust close focus.
	Zoom Out	Zoom out screen or adjust distant focus.
Trackpad		<ul style="list-style-type: none"> • Slide on the trackpad to move the mouse cursor. • Press the trackpad to confirm operations. • Using two fingers to press on the trackpad and slide up/down for page up/down.

Capturing Screenshot Using the Remote Control

To capture a screenshot on GVC3220, the users can press the red shortcut key  and blue shortcut key  at the same time for about 3 seconds. The screenshot picture will be saved in the internal storage of GVC3220. The users can access the screenshot in GVC3220 LCD menu → **Applications** → **File Manager** → **Internal Storage** → **Pictures** → **Screenshot**.

Please note the screenshot folder will include two pictures: The image captured from the camera and the TV/Monitor screenshot.

Using the Remote Control

GVC3220 remote control is connected to GVC3220 via Bluetooth, and it is already pre-paired when the user receives GVC3220 packages. Before using the remote control, please make sure:

1. Four AAA batteries are correctly installed on the back of the remote control.
2. The remote control needs to be placed within the Bluetooth effective range, i.e., 10m from GVC3220.

After powering up GVC3220, pressing "OK" key on the remote control, it will initiate connection and the remote control can be used right away.

If the remote control fails to pair and connect to GVC3220, please follow the steps below to troubleshoot:

- Check the battery polarity when placed into the battery case. Make sure the batteries are placed in the correct direction in the remote control.
- Check the battery power.

Notes:

If GVC3220 remote control still does not work with the diagnosis above, please try another remote control or contact the device provider.

Starting from firmware 1.0.1.35, controlling the camera in Teams and Zoom Third Party Applications is supported via PTZ.



For Teams meeting:

- The navigation keys control the PTZ
- Double click the Trackpad to bring and navigate in the meeting settings.

For Zoom meeting:

- The navigation keys control the PTZ
- Use the trackpad to bring and navigate in the meeting settings.
- When the left button of the remote control is pressed it brings the safe driving mode, the video is stopped and the GVC camera moves accordingly.

Using Mouse & Keyboard

When the USB mouse is plugged into GVC3220, users could make the following operations with the mouse.

- Single click the left key of the USB mouse to perform the following operations:
 - Access menu
 - Check in the checkbox or enable/disable an option.
 - Bring up the drop-down list when clicking on a combo box
 - Switch input methods in the input box, tap on the corresponding buttons on the soft keyboard to input characters
- Double left clicks  on the soft keyboard can switch to "Always use upper case" in English input method.
- Single click the right key of the USB mouse to exit the current displayed menu. It will go back to the previous menu without saving the configurations.

Using the LED Indicator

GVC3220 LED indicator can be used to notify the users with current status of the device. Please refer to the status description below.



Table 5: GVC3220 LED Indicator Status Descriptions

LED Indicator Status	Descriptions
Solid Green	Booting or the device is already booted up
Flash Green (per 0.5s)	Pressing any button on the remote control
Flash Red (per 1s)	<ul style="list-style-type: none"> ● Rebooting ● Upgrading ● Factory Reset
Flash Red (per 0.2s)	<ul style="list-style-type: none"> ● Temperature > 80 degree ● Camera connection failed
Flash Red (per 2s)	Sleep mode
Solid Blue	<ul style="list-style-type: none"> ● Recording ● The device is in a call
Flash Blue (per 0.5s)	Pairing the remote control
Blue/Red Alternately	Aging test
OFF	Power off

Status Icons

GVC3220 status icons are displayed on the right side of top status bar on GVC3220 LCD display device. The users can view the top status bar notification details in drop-down panel by long pressing the MENU key on the GVC remote control or pressing UP button when the GVC3220 is in home screen.




Figure 7: GVC3220 Top Status Bar Dropdown Menu

For some notifications such as Schedule, Voice Mail..., the users can use the GVC remote control trackpad to select it. It will navigate the users to the corresponding app.

The following table lists the main status icons used on GVC3220.

Table 6: GVC3220 Status Icons Descriptions

Icon	Descriptions	Icon	Descriptions	Icon	Descriptions
	Missed Call		Ongoing call		Auto answer is enabled
	Ethernet is connected		Ethernet is disconnected		Trying to connect to the Ethernet
	PPPoE is connected		PPPoE connection is failed		PPPoE is disconnected
	VLAN is successfully configured		VLAN is being configured		Unread voicemail
	VPN is connected		VPN connection is failed		Wi-Fi-Display is opened
	Bluetooth is connected		DND mode is enabled		Download or read firmware errors
	Remote control Low battery		Remote control is connected and paired		Remote control is not connected and paired
	Micro SD Card is inserted		USB flash drive is inserted		Speaker is being used
	Volume is turned to silent		Contacts storage is full		SD card storage is full
	Wi-Fi is connected.		Wi-Fi is disconnected		Unknown Wi-Fi
	Call forward is set up	 Wi-Fi signal strength			

Using the Onscreen Keyboard

English Keyboard

This is the default keyboard on GVC3220. The English keyboard supports multiple languages input methods. See figure below:



Figure 8: Soft Keyboard - English Input Method

Notes: Tap on  to switch Caps Lock:

Numbers and Symbols

To input numbers and symbols, tap on button  on the default keyboard to switch to numbers/symbols.




Figure 9: Soft Keyboard - Symbols and Numbers

Home Screen

GVC3220 Home screen displays the icons for users to easily access applications, camera, schedule, call, contacts, and settings. Press the navigation keys on the GVC3220 remote control to select an option.

Note: GVC3220 will not automatically hide the main interface. You need to manually press the back key to

enter the Camera. Press OK button on the GVC3220 remote control to bring up the icons to display again.




Figure 10: GVC3220 Home Screen

GVC3220 Menu

Every menu opens a list of options. Press Arrow keys to navigate to the menu option you require. Then press **“OK”** to access further options or confirm the setting displayed. To go to the previous menu item,

press  **“Back”**. You can press  **“Home”** key at any time to cancel and return to Home screen.



Screen Lock

The GVC3220 supports screen lock. When it is enabled and configured, the user will be required to enter the lock code to unlock on the home screen. To use this feature, follow the below steps:

1. On GVC3220 LCD Menu → **Settings** → **Advanced** → **Security**,
2. Select **“Screen Lock and password”**. Then, set Screen Lock code.




Figure 11: Screen Lock Password

3. Reboot, enter sleep mode or power off the GVC3220.
4. When the GVC3220 boots up again, a screen lock code will be required. The user can unlock the screen by entering the code using the GVC remote control.

System Configurations

The users can adjust the GVC3220 system configuration under LCD Menu → Settings → System.




Figure 12: Settings – System

HDMI Settings




Figure 13: System - HDMI Settings

- **HDMI 1 Output:** Set HDMI 1 out resolution. Up to 1920x1080p60 resolution, default is 1080p (depending on TV resolution).
- **HDMI Screen percent:** The user can configure screen percent from 90% to 100%. This adjusts the image size displayed on the monitor. Use this option when output device (for example, LCD monitor or TV) is unable to display the GVC3220 screen completely.
- **Others:** Image Mode, HDMI 2 Output Resolution (This parameter will be set to “Disconnected” if the interface is not used) and HDMI Consumer Electronics Control (Auto turn off the Device/TV).

Site Name



Figure 14: System - Site Name



- **Site Name:** Configure the site name to be imposed on the video of local video.
- **Display Position:** Configure the site name's position to be at the Upper Left Corner, Upper Right Corner, Lower Left Corner or Lower Right Corner on the video. The default setting is "Upper Left Corner".
- **Display Duration:** Configure the duration to display the site name. The user can select Do No Display, 1 Minute, 5 Minute, 10 Minutes or Always display. The default setting is "Do Not Display".
- **Advanced settings:**
 - Transparency Set the display background transparency to be Opaque, 5%, 10%,15% and 20%. The default setting is "Opaque".
 - Horizontal Offset Slide left or right to adjust the horizontal position from 0 to 96 for the site to display on the screen. The default setting is 0.
 - Vertical Offset Slide up or down to adjust the vertical position from 0 to 96 for the site to display on the screen. The default setting is 0.
 - Font Color Select the color in which the site name is displayed. The default color is white.
 - Font Size Select the font size from smallest to largest for the site name to display. The default value is Medium.
 - Bold Configure whether the site name is displayed in bold. The default setting is "Disabled".



Storage




Figure 15: System Storage

- Display GVC3220 Internal storage details.

App & Application account

The latter options display available/installed Applications and the related Google Accounts used




Figure 16: Available Apps List

Note: User can manage their google account through the “Application Account” section




Figure 17: Add Google Account



Note: The GVC3220 administrators have access to multiple advanced options through LCD Menu Settings. The “**Network**” section is dedicated for Ethernet/Wi-Fi connection parameters. The “**Basic**” section allows Language, Date/Time, Audio/Video, Power and Wireless Managers configurations. The “**Status**” section holds the Accounts, Interfaces and Remote control state detection and modifications. As for the “**Advanced**” section, it will provide Web Access configuration, Security Settings, Maintenance parameters (Upgrade...) and Troubleshooting tools.

For more information, please refer to The GVC3220 Admin Guide.

CONNECTING TO NETWORK AND DEVICES

GVC3220 supports a variety of network connections (Ethernet, Wi-Fi) and device connections, including USB, SD card and Bluetooth devices. When the GVC3220 boots up for the first time, a setup wizard will guide the users to pair and connect the remote control to GVC3220 and get started with the basic configurations.

Ethernet

If the user would like to use Ethernet connection for network access, please plug the Ethernet cable into the LAN port on the back of GVC3220. Ethernet connection is turned on as DHCP by default on both IPv4 and IPv6 protocols. To configure Ethernet settings on GVC3220, go to LCD menu → **Settings** → **Network** → **Ethernet**.




Figure 18: Ethernet Settings

The GVC3220 offers the possibility to prioritize a protocol over another by setting Preferred Internet protocol to IPv4 or IPv6.

Using IPv4

To configure the GVC3220 using IPv4 protocol, follow the below steps:

1. Plug the Ethernet cable into the LAN port on the back of GVC3220.
2. Go to LCD menu → **Settings** → **Network** → **Ethernet** → **IPv4 Settings**.
3. Tap on "Address Type" to select DHCP, Static IP or PPPoE as the address type.
 - For DHCP, save the setting and GVC3220 should be able to get IP address from the DHCP server in the network.






Figure 19: IPv4 Settings - DHCP

- For static IP, enter IP Address, Subnet Mask, Default Gateway, DNS Server, and Alternative DNS server for GVC3220 to correctly connect to the network.



Figure 20: IPv4 Settings - Static

- For PPPoE, enter PPPoE account ID and password so that GVC3220 can get IP address from the PPPoE server.




Figure 21: IPv4 Settings - PPPoE

Notes:

- Press  to Save configuration
- Press  to Cancel configuration

Using IPv6

To configure the GVC3220 using IPv6 protocol, follow the below steps:

1. Plug the Ethernet cable into the LAN port on the back of the GVC3220
2. Go to LCD menu → **Settings** → **Network** → **Ethernet** → **IPv6 Settings**.
3. Tap “Address Type” to select DHCP or Static IP as the address type.
 - For DHCP, save the setting and GVC3220 should be able to get IP address from the DHCP server in the network.




Figure 22: IPv6 Settings - DHCP

- For static IP, configure IPv6 address, DNS server 1, DNS server 2 and Preferred DNS server, enter the IPv6 address in the format of 2001:db8:1:2::3.




Figure 23: IPv6 Settings - Static

WI-FI

Wi-Fi is supported and built-in on GVC3220 only. On the LCD display, go to **Settings** → **Network** → **Wi-Fi** to turn on and configure Wi-Fi.






Figure 24: Network Settings

Turning Wi-Fi On/Off

Once Wi-Fi is turned on, GVC3220 will automatically start the scanning within the range. A list of Wi-Fi networks will be displayed as scanning result. Tap on the SSID and enter the correct password information to connect to the selected Wi-Fi network.




Figure 25: GVC3220 Add Wi-Fi Screen

Notes: Press  to connect to a hidden Network




Figure 26: Add Network

- Press  to Scan for available Wi-Fi Networks
- Press  to Access advanced Wi-Fi Options. The dialog will show additional option "IP settings". Select Static IP, enter IP Address, Subnet Mask, and Default Gateway for GVC3220 to correctly connect to the network.

Wireless Projection

Wi-Fi Projection feature is used for screen stream mirroring of other devices in the GVC3220 via Wi-Fi.

Please refer to the following steps to display your device's screen on the GVC3220 screen:

1. On the LCD display, go to **Settings** → **Network** → **Wireless Projection**
- Set "Open" to enable Wireless Projection Option.




Figure 27: Wireless Projection

2. On the device you want to cast its screen, go to "Screen mirroring" feature page and enable Wireless projection.
3. The phone will show the GVC3220 in the available devices list.
4. Select the GVC3220. The screen mirroring will start immediately.

LLDP and VLAN Settings

Access GVC3220 home screen, go to **Settings** → **Advanced** → **Network Advanced Settings** → **Additional Network Settings** to configure LLDP settings on GVC3220.






Figure 28: LLDP/VLAN Settings

Notes:

- Press  to Save configuration
- Press  to Cancel configuration

Table 7: GVC3220 LLDP Configuration Parameters

Parameters	Descriptions
LLDP	
LLDP	Enable or disable LLDP. The default setting is “Open”.
Layer 3 QoS for SIP	This field defines the layer 3 QoS parameter for SIP packets. It is the value used for IP Precedence, Diff-Serv or MPLS. The default value is 26.
Layer 3 QoS for Audio	This field defines the layer 3 QoS parameter for audio packets. It is the value used for IP Precedence, Diff-Serv or MPLS. The default value is 46.
Layer 3 QoS for Video	This field defines the layer 3 QoS parameter for video packets. It is the value used for IP Precedence, Diff-Serv or MPLS. The default value is 34.
VLAN	
Layer 2 QoS 802.1q/VLAN Tag	Assigns the VLAN Tag of the Layer 2 QoS packets for LAN port. The default value is 0. Note: Please do not change the setting before understanding the VLAN's settings or consulting with the network administrator. Otherwise, the device might not be able to get the correct IP address.

Layer 2 QoS
802.1p Priority

Assigns the priority value of the Layer 2 QoS packets. The default value is 0.

802.1X Mode

Under **Settings** → **Advanced** → **Network Advanced Settings** → **802.1x**. By default, 802.1x is disabled. Selecting 802.1x mode to "EAP-MD5", "EAP-TLS5" or "EAP-PEAP" to turn on 802.1x. Once it is enabled, the user will be required to enter the identity and password to be authenticated in the network.




Figure 29: Network Advanced Settings




Figure 30: 802.1X - EAP-MD5




Figure 31: 802.1X - EAP-TLS






Figure 32: 802.1X - EAP-PEAP

Table 8: GVC3220 802.1x Mode Parameters

Parameters	Descriptions
802.1x Mode	Allows the user to enable/disable 802.1x and configure 802.1x mode. The default setting is disabled.
Identity	Enter the Identity information for 802.1x mode.
MD5 Password	Enter the MD5 Password for 802.1x mode.
CA Certificate	Upload the CA certificate for 802.1x mode.
Client Certificate	Upload the CA certificate for 802.1x mode.
Private Key	Upload the private key for 802.1x mode.


Proxy

If your network requires going through a proxy, you can configure the proxy server, port, and bypass options under **Settings** → **Advanced** → **Network Advanced Settings** → **Proxy**.


Figure 33: Proxy

Figure 34: Proxy Settings

CAMERA

Users could set preset, configure camera parameters, start recording and make screenshots on camera screen. There are 3 ways to access camera screen:



- Click on Camera icon on home screen.
- Press key  on the remote control.

GVC3220 camera screen has the following options:

- Press recording button on the remote control to start or stop local recording.
- Press the red shortcut button on the remote control to edit preset.
- Press the yellow shortcut button on the remote control to edit image parameters such as scene, white balance, MF/AF and etc.
- Press the blue shortcut button on the remote control for screenshot.
- Press digit key on the remote control to apply a pre-configured preset.




Figure 35: GVC3220 Camera Screen

Preset

Add Preset

Users can create and save maximum of 24 camera presets, with each preset storing the camera position and focal length. Follow the steps below to add preset:

1. Access camera screen and press  on the remote control to access preset screen.





Figure 36: GVC3220 Add Preset Screen

2. Select the preset window and press the blue shortcut key on the remote control to access the editing screen.
3. Adjust camera position and zoom in/zoom out using the remote control.
4. On GVC3220 remote control, press "OK" key to save the preset, or press Back key  to cancel.

Notes:

- Press  to Delete Preset
- Press  to Rename Preset
- Press  to Edit Preset

Camera Parameters Configurations

Press  shortcut key on GVC3220 remote control to bring out camera parameters setting screen as shown below. Refer to the table below and configure the parameters using navigation keys on the remote control.




Figure 37: GVC3220 Camera Parameters Setting Screen

Table 9: GVC3220 Camera Parameters

Parameters	Descriptions
Picture Mode	<p>GVC3220 has 5 built-in modes as well as "Manual" for customization. When set to "Manual", press "OK" key to access each setting to configure sharpness, contrast, saturation, and brightness.</p> <ul style="list-style-type: none"> • Sharpness: Higher sharpness brings higher screen clarity. The object displayed on the screen has more sharpen edge. • Contrast: Higher value brings more distinct color contrast. • Saturation: Higher value brings deeper color. • Brightness: Higher value brings brighter color.

White Balance	<p>This is used to display accurate images. Users could set to "Manual" or "Auto".</p> <ul style="list-style-type: none"> When set to "Auto", the device will adjust parameters automatically according to the current environment. When set to "Manual", the device will disable "Auto" mode. Press "OK" key to access manual setting screen and adjust red or blue gain manually for better white balance.
De-noise	<p>Users could set to "off", "low", "medium" or "high". Higher reduction level brings less image noises.</p>
Camera Speed	<p>This option allows configuring the moving speed and zoom speed for the camera. "1" is the slowest and "16" is the fastest. The default is "8".</p>
Frequency of A.C.	<p>Users could set to 50HZ or 60HZ.</p>
Initial Position	<ul style="list-style-type: none"> System default position: The GVC3220 will boot up at default camera position. Position when power off: The GVC3220 will return to the last position before power off. Custom: The GVC3220 will boot up at a custom position. When chosen, users will be redirected to Preset settings page to set a custom preset.
Red Shortcut Key (MF+)	<p>Manual focus: increase the focal length.</p>
Yellow Shortcut Key (MF-)	<p>Manual focus: decrease the focal length.</p>
Blue Shortcut Key (AF)	<p>Auto focus</p>

PERIPHERAL

External USB Device

GVC3220 USB interface could be connected with a USB mouse, a USB keyboard, or a USB storage device.

Using USB Mouse/Keyboard

When a USB mouse is plugged into GVC3220, users could see the cursor on the screen, move the cursor to perform operations. When a USB keyboard is plugged into GVC3220, users could use GVC3220 remote control to navigate to an input interface and click on the keys on the keyboard to check if it is installed successfully.

Storage Device

To connect and access USB storage device:

1. Insert the storage device into the proper port at the back of GVC3220 (USB or SD Card).
2. It will take a few seconds for GVC3220 to prepare the connection.
3. Once it is installed successfully, the USB/SD Card icon will show up on the status bar. Users could go to GVC3220 LCD → **Applications** → **File Manager** → **USB/SD Card** to access and manage your data.




Figure 38: Storage Device



4. Users could view, copy/paste or delete files on the USB storage device.




Figure 39: Browse Storage Device

Notes:

- The external SD card must be plugged in if the users would like to record calls and the recording files will be automatically saved in the external SD card. It is recommended to use an SD card with large capacity for call recording purpose.
- For more information, please refer to the [**File Manager**] section in this document.

Microphone and Speaker

Users can connect external audio devices as audio input/output sources. It is recommended to use the external speaker GMD1208 that comes with your GVC3220 package for better compatibility. For more information, please refer to the [**Connecting GMD1208 to GVC3220**] section in this document.

If the external speaker supports Bluetooth, users could also pair and connect the speaker to the GVC3220 via Bluetooth. This will provide better mobility and make cabling easier when deploying the GVC3220 conference system in your conference room.



Notes:

- Users could go to GVC3220's **Menu → Settings → Basic → Audio** to check the current Audio Input/output device. Kindly refer to the screenshot for the new adding feature:
- The Audio Calibration will help filter the HDMI to improve the output audio quality of the external HDMI device.




Figure 40: Audio Calibration

MAKING PHONE CALLS

Account

GVC3220 comes with one IPVideoTalk account, supports one configurable SIP account registration, one H.323 account, one Blue Jeans account and one Zoom account. Please enable the IPVideoTalk account or register SIP account to a SIP server before making calls. The following figure shows the IPVideoTalk account is registered successfully. This displays on the left side of the top status bar on your LCD display device.



Figure 41: GVC3220 IPVideoTalk Account

Dial Screen

Once the account is registered successfully, users could use one of the following 2 ways to bring up dial screen to start making calls.

- Press the SEND  button from the remote control.
- On the LCD display device, click on icon  on home screen.

Enter digits in the dial-up box. If the digits or the letters for the digit match contacts and call history in GVC3220, a dropdown list of numbers will be displayed. For example, entering 5 (JKL), 6 (MNO), 4 (GHI) and 6 (MNO) will display “5646” or “john” if contact “john” exists. The matching characters will be highlighted in red.

- Press the BLUE shortcut key on the GVC3220 remote control to switch accounts
- Press the RED shortcut key to switch between Audio/Video Call
- Press END CALL  button on the remote control to cancel the call.




Figure 42: GVC3220 Call Screen

Dialing a Number Directly

1. On the dial screen. Use the remote control keyboard to enter digits or click the input box to enter digits using the pop out soft keyboard.
2. Press  on the remote control OR move the cursor to the icon  (Audio Call) /  (Video call) on the dial screen to dial out.

Notes:

- By default, GVC3220 allows users to press # key as SEND key. This behavior can be disabled via option "Use # as Dial Key" in web GUI → **Account** → **SIP/Bluejeans/Zoom** → **Call Settings**
- When entering initials or full spellings of a name that exists in the contact, this contact will show up in the dropdown list. For example, if the user inputs Amy by pressing the corresponding digits "2" (ABC), "6" (MNO), "9" (WXYZ) on the remote control, Amy's name and number will be displayed in the list if it exists in the contact, users can select it to dial out.



Dialing BlueJeans/Zoom call

GVC3220 has built-in access for users to dial BlueJeans/Zoom calls. Follow the steps below:

1. On the LCD dial screen, press the BLUE shortcut key on GVC3220 remote control to switch call mode from SIP Call to **BlueJeans** or **Zoom** Call.





Figure 43: BlueJeans/Zoom Call Screen

2. When the call mode shows **BlueJeans** or **Zoom**, input BlueJeans/Zoom conference ID and conference password.
3. Press  on the remote control or click on the screen buttons  \  to dial out a video\Audio call.
 - Click on  for to switch between call modes (video or audio)

For more information about how to use BlueJeans on GVC3220, please refer to the link below:

http://www.grandstream.com/sites/default/files/Resources/GVC3220_BlueJeans_application_note.pdf

Redial

Users can dial out the last dialed number if there is dialed call log. Access the dial screen, and then press "#" key or  on the remote control to dial out.

Dialing a Number via Contact

Follow the steps below to dial a number via Contacts:

1. On the LCD display device, access Contacts by tapping on button  on home screen.
2. Navigate and select in the contacts entries using the remote control navigation keys.
3. Press  on the remote control to dial out.

Dialing a Number via Call History

1. On the LCD display device, access Applications on home screen and access call history by selecting the icon .
2. The LCD will display all call history types. Navigate in the call history list by selecting the call history category. Select the call history entry you would like to dial out.
3. Press  on the remote control to dial out.

Direct IP Call


Direct IP Call allows GVC3220 and another VoIP device to talk to each other in an ad-hoc fashion without a SIP proxy. Direct IP calls can be made if:

- Both GVC3220 and VoIP phone have public IP addresses, Or
- Both GVC3220 and VoIP phone are under the same LAN / VPN using private or public IP addresses, Or
- NAT is disabled or GVC3220 NAT is disabled.

Both devices can be connected through a router using public or private IP addresses (with necessary port forwarding or DMZ).



To make a direct IP call, please follow the steps below:

1. Access the dial screen on GVC3220 LCD.
2. Press  the RED shortcut key on the remote control to bring up call mode setting screen, set the mode to "SIP".
3. Input the target IP address. For example, if the target IP address is 192.168.124.123 and the port is 5062, input the following:

192*168*124*123#5062

The * key represents the dot (.) and the # key represents the colon (:).
4. Press  the BLUE shortcut key on the remote control to select "Audio Call" or "Video Call".
5. Press  on the remote control to dial out.

Paging/Intercom

Before placing paging/intercom, please make sure the callee has paging/intercom enabled so that it can answer the paging/intercom call automatically. To make paging/intercom call:

1. Access the dial screen on GVC3220.
2. Enter the number to dial followed by *74. Please refer to [**Call Features**] for more details.
3. Press  the BLUE shortcut key on the remote control to select "Audio Call" or "Video Call".
4. Press  on the remote control to dial out.

Contacts

GVC3220 Contacts app helps users to easily store and manage phone numbers and contacts information. Users can add contacts on GVC3220 or import contacts from external devices as well as download from a server. On GVC3220 home screen, click on "Contacts".




Figure 44: Contacts






Figure 45: GVC3220 Contacts Screen

- **Local Contacts:** It is used to display all contacts.
- **Local Groups:** It is used to view groups. Select one group to view group details.




Figure 46: Contacts - Local Groups

- **Enterprise Contacts:** It is used to view IPVideoTalk contacts

- **Operations**

- **Search:** Users could input keyword to search in the dialog. GVC3220 will display contacts automatically which is related to the search keyword. Fuzzy search and precise search are both supported.
- **Call:** Select the contact and press OK or  on GVC3220 remote control or click on the screen button to dial the contact users would like to call.
- **Add:** Press  shortcut key on the remote control to access New Contact screen, fill in contact information and press the yellow shortcut key on the remote control to save it.
- **Edit:** Press the yellow shortcut button on the remote control
- **Batch remove:** Press the red shortcut key to access the contact delete screen. Select the unwanted contacts and delete using the RED button.




Figure 47: contact delete screen

- **Contact Details:** Select one contact and press "OK" key on the remote control to dial

Add Contact/Group

Add Single Contact

Follow the steps below to add one single contact:

1. Press the blue shortcut key on GVC3220 remote control to access New Contact screen.




Figure 48: GVC3220 Add New Contact Screen

2. Enter the contact information.

Note: This screen allows assigning the Contact to a Local Group

3. Press the red shortcut key to add more contact information.
4. Press the yellow shortcut key to save the contact information.




Figure 49: New Contact - More Fields

Add Group

Available under **LCD Menu** → **Contacts** → **Local Groups** → **New**.




Figure 50: New Group

1. Input a group name and tap on "OK" to add a new group.
2. Go to Contacts Screen to find the group you just added and access it.

3. Press the YELLOW shortcut key on the remote control to access Groups editing screen.
4. Select the contacts to add to this group.
5. Press the YELLOW shortcut key on GVC3220 remote control to save.

Answering a Call

When the device is in idle and there is an incoming video call made by SIP or IPVideoTalk account, the device will show the call screen as below:





Figure 51: GVC3220 Single Incoming Call Screen

-  or “Pick up” button on the remote control. or select  to reject the call.
- When there is an incoming call during an active call, users will hear a call waiting tone with the LCD displaying the caller name and ID for the incoming call.




Figure 52: GVC3220 New Incoming Call Screen

- Users could select  to answer with audio only.

Call Hold

During an active call, press HOLD button  to put the call on hold.




Figure 53: Hold screen

- The GVC3220 displays the ongoing conversation time on the bottom right of the screen
- On the LCD display, click on  to resume the call. Users can also click on  or press  on the remote control if they wish to end the call.
- If the current call is a video call, the screen will not display remote video when the call is on hold.

Mute Local Audio

During an active call, press the MUTE button  to mute the call, press the button again to unmute the call.

OR, go to GVC3220 Call screen →  Menu →  Mute




Figure 54: Mute screen

Call Recording

During an active call, users could record the video to the external SD card plugged into GVC3220. Once recorded, users can view the recorded video in Recorder application, and download the video from web UI

→ **Maintenance** → **Recording**. For more details, please refer to the chapter **[Record]**.

1. During an active call, press the recording key  on the remote control. A red Rec icon will show up on the upper left of the screen.
2. The recording files will be saved to the configured save path automatically when the call is finished.

Users could also press  on the remote control to stop recording anytime.

OR, go to GVC3220 Call screen →  →  (Audio & video) /  (Audio only)

Note : The call screen will display  when enabling IPVideoTalk recording,  and  for video and audio recording, respectively.

DND (Do Not Disturb)

When DND is on, the incoming calls to GVC3220 will be blocked without ringing. Users could see the blocked calls in call history. Once it is enabled, the DND icon  will be displayed in the status bar on the top of the screen.

- When GVC3220 is in idle screen, users can press  button on the remote control to turn on/off DND.
- When GVC3220 is in an active call, users could turn on/off DND in call screen. This will not affect the current call, and it will take effect starting from the next incoming call.


• At any time, users could log in GVC3220 Call screen →  →  to turn on/turn off DND.


- The status bar will notify that DND is activated:



192.168.5.142  IPVideoTalk (8208539) Do Not Disturb has been enabled       11:33

Missed Call



When there is a missed call, the call icon  on home screen will show the number of missed calls.

Once accessed the dial screen, the reminder icon will disappear.




Figure 55: Missed Call notification

Call Forward

Call forward (Unconditional/No Answer/Busy/Time Based) can be set up from web GUI. Log in GVC3220 web GUI and go to **Account → SIP → Call settings**. For details, please refer to "GVC3220 Administration Guide".

Conference

Device Layout

GVC3220 supports up to 5-way 1080P video conferences. it can either be the host to initiate a conference or join other conferences as a member.

Users can connect multiple HDMI output devices for conference. HDMI 1 interface is the primary output when plugging in multiple HDMI display devices. The device connected to HDMI 1 interface will display local site by default while other devices automatically display remote sites. If the HDMI IN device is plugged in to GVC3220, the device connected to HDMI 1 interface displays presentation of HDMI input while other devices will display video view.

During a conference, user can tap on  button on GVC3220 remote control to go back to HOME screen, with the conference video displayed in the background.



Initiating Conference

The conference can be initiated in multiple ways:

- **From Call Screen:**
 1. Access the call screen, enter the numbers in the text box or select members from the list below.
 2. Press  on the remote control or click on “Call” button on the screen to dial out.




Figure 56: Call Screen

- **From Schedule:**

For more details, please refer to section [**Schedule**] from this document.

Answering an Incoming Call in Conference

You can specify how your GVC3220 handles incoming calls. Depending on your configuration, your GVC3220 answers a call automatically or prompts you to answer a call manually:

- Log in GVC3220 web GUI and go to **Account** → **SIP/H323** → **Call settings** and set "Auto-answer" option to "Yes". All incoming calls will be answered automatically. If it is a video call, it will be answered with video as well.
- If "Auto Answer" is set to "No", users will need to select to answer with video manually, audio or reject the call using the remote control on the LCD prompt.
- If the conference host answers the call, the caller will join into the current active conference.

Conference Management

The following figure shows a 3-way conference:



Figure 57: GVC3220 3-Way Conference

On the bottom of the call screen, users will see a list of icons for menu options. This menu will be automatically hidden if there is no operation in 5 seconds. Press any key to bring up the menu options again. Here are the functions for each icon.

Table 10: GVC3220 Call Screen Bottom Menu Icons

Icons	Name	Definitions
	Add Member	Access dial screen and add more numbers to join conference.
	Layout	<p>Adjust the layout for the video display for video call. The layout options might vary depending on how many video participants are in the call, how many HDMI outputs are connected and whether presentation is turned on or not.</p> <p>The user can choose to adjust “Local Layout” in order to choose a layout for its own GVC3220, or to adjust “Cloud Layout” to choose a layout that will be shown for all the participants of the conference (this feature needs to be supported on the server side).</p> <p>For example, in a two-way video call on GVC3220 which has one HDMI output connected, after pressing “Layout” icon, users will see options “Average”, “Remote (Local)”, “Local (Remote)”, “Remote” and “Local”.</p>
	Camera	Open Camera Control, this feature is used to control the remote GVC32xx camera functions such as pan, tilt and zoom.

 Menu		Enable/Disable GVC3220 audio stream.
		Enable/Disable GVC3220 video stream.
		<p>Control video and audio for the host (Me) or other conference members (Participants). It includes the following options:</p> <p>  - The selected party will not be heard by other parties.  - The video call with the selected party will turn into audio call. If the user clicks on this icon again, a video invitation will be sent to this party. The party has to accept the video request in order to see the video again.  - Lower the hand of a user (from the participants list) or lower all hands (from Conf Control).  - Delete member from the conference  - Turn Off /On the Local Camera </p>
		Start/Stop recording the ongoing conference. The recording files will be available from [Record] application.
		Start/Stop Audio recording the ongoing conference.
		<p>Pause/resume conference.</p> <p>Once the conference is paused, the device will stop sending local video/audio to the remote parties.</p>
		Enable or disable DND.
		To enter DTMF digits during the call.
		This is to set a PIN code to lock this conference call. Once the conference call is locked, the caller who wants to join this conference by calling the conference host must enter the PIN code.
		Display conference information such as Subject, Meeting ID, Organizer, URL, Host Code and Server Area
		Display call details such as video packet loss rate, video bit rate, video frame rate, video codec, video resolution, audio packet loss rate, audio bit rate and audio codec for both sending and receiving parties.

	Click to raise hand
	Click to put hand down
	End End conference and go back to home screen.

- If the remote party is also a GVC3220, you can press the camera key  on the remote control to control PTZ device for the remote party.
- During an active conference call, if there is a new member joining conference, an outgoing call failed or a member hanging up, there will be a prompt box on the left side of the conference screen showing notifications. The notification prompt will be hidden automatically if there is no new notification in 2 seconds.
- On the right side of the video conference screen, users can see member status such as audio/video calls, or whether if the call is being muted.

Table 11: GVC3220 Conference Member Status Descriptions

	The current line is in an audio call.		The current line is being muted.
	The current line is in a video call.		The current line is not connected.

- On the upper left side of the video conference screen, users can see an icon  to indicate network unstable condition, which means the current network condition is not good enough for the video call using the selected resolution/bit rate.

Invite Members to Conference

Users could use one of the following ways to add members:

- Access the dial screen by clicking on the ADD icon  on conference screen. Then, enter the number to dial out. Once the member answers the call, it will be connected into the conference automatically.
- When GVC3220 is on conference screen, press  on the remote control to access the call screen. Then, enter the number to dial out. Once the member answers the call, it will be connected into the conference automatically.

- The member calls the conference number. If the host answers the call, the member will be added into conference automatically.

Conference Control

Tap  on to make operations such as mute, disable sound, camera control and suspend video. The conference control screen is as shown below:




Figure 58: GVC3220 Conference Control Screen

1. Use Up/Down navigation keys on GVC3220 remote control to select conference member.
2. Use Left/Right navigation keys on GVC3220 remote control to make operations, press "OK" key to confirm the operation, press "OK" key again to cancel, e.g. tap on to mute one member and the icon will turn to tap on it again to restore.
3. To remove a member from the conference, click on the DELETE icon on conference screen. Select the member from the member list and press "OK" key to delete it.

Note: Users can press the "Meeting Control" card on the meeting control screen to mute all, block all or suspend videos.




Figure 59: Conference Control Operations

Pause Conference

The video will be stopped if the conference is paused. You will not see the video view of the members and the other members will not see your video either.

Notes:

1. The new incoming call will be rejected if the conference is paused.
2. The presentation will be displayed normally when the conference is paused.

Conference Layout

During a video conference, users can customize screen layout when using multiple connected HDMI outputs, to specify particular video feeds to be displayed on each screen.

Under GVC Call screen → **Layout**, users can choose the most convenient layout.




Figure 60: Layout customization

- **Local Layout:** Users can choose the local layout that will be shown only on the GVC3220 where the local layout was adjusted, and not for all the participants. The available local layouts are: Average, PIP (Picture in picture) and Full screen display.




Figure 61: Local Layouts

- **Cloud Layout:** The host user can choose a cloud layout to be used for the whole conference and will be shown for users as well (this feature needs to be supported by the server as well). The available Cloud Layouts are: Tile, Solo, 1+3, 1+5, 1+7, Speaker.




Figure 62: Cloud Layouts

- When **solo mode** meeting layout is set: Users could specify a pane to display a certain participant.
- When **Speaker mode** meeting layout is set: Users could specify a pane to display a certain participant. The speaker can view all participants video images, and the participants can only view the speaker's video image.

- **Focus 1+N:** There are 3 modes for users: “1+3” layout, “1+5” layout, and “1+7” layout, which means one large video image with N smaller video images (polling mode).

Presentation Sharing

GVC3220 supports dual stream video, with the presentation sharing function, you can connect HDMI input devices or wireless devices (that support screen mirroring). And share the input sources with remote parties while they can still view the local video.

To share a presentation please follow the below steps:

1. Link the GVC to your presentation device
 - **Cable link:** Users can connect a PC/Laptop to the HDMI in port
 - **Wireless link:** Users can enable Wi-Fi and use Wi-Fi Projection option under **Settings** →

Network

For more information please refer to **[Wireless Projection]** section in this document.

2. Share screen during an ongoing conference call
 - Users can simply press the presentation button  on the Remote control. Or, click on presentation from the call menu
3. All the participants should be able to visualize the mirrored screen as shown on the figure below.





Figure 63: GVC3220 3-Way Conference with Presentation

Web GUI Sharing

The GVC3220 allows sharing the management device screen during a conference call. This applies to any device from where you can log in and access the GVC3220 web configuration interface. The feature can be enabled by proceeding as follows:

1. Set HTTPS as Web Access Mode under **GUI → System Settings → Security Settings**.
2. During an ongoing conference call, click **“Share Screen”** option from the Web GUI tool bar.




Figure 64: Enable Web GUI Screen sharing

3. A pop-up window will allow you to choose which screen to share
 - The GVC3220 will include two of the available screens, open browser and running applications on the device from where you have accessed the Web GUI.




Figure 65: Web GUI - Share your screen

- Audio sharing can be enabled/disabled at the bottom of the pop-up window
 - Complete your selection. Then, click on **“Share”**.
4. Notice the RED ball on the browser window, indicating that screen sharing is enabled
 5. Stop the Web GUI screen sharing at any given moment by pressing the related button from the tool bar.




Figure 66: Stop Web GUI Screen sharing

Participants List

Users could check all participants in the current IPVideoTalk meeting. If the meeting host does not allow the participants to check all members, the participants cannot see all members in the meeting.

During IPVideoTalk meeting, click on “Conf control”  and GVC3220 will show all participants in the current IPVideoTalk meeting, including all participants with all types of clients.




Figure 67: GVC3220 Participants List

Call Details

Users could view audio and video details of the conference members. On the conference screen, click on



Menu and select




Figure 68: GVC3220 Call Details Screen

Conference Lock

Users could lock/unlock the scheduled conference. Once it is locked, the other incoming calls will not be

able to join the conference. The locked scheduled conference will display  icon on the screen.

Open DTMF

Users can dial DTMF during a conference.

1. On GVC3220 remote control, click on Menu button then select  on the conference screen to bring up the DTMF input screen.




Figure 69: Conference - Dial DTMF

2. Press the digital keys on the remote control to input DTMF. Press  to cancel the operation if needed.

PIN Code

During the conference call, the conference host can set a PIN code to lock the call. Once the conference call is locked, the caller who wants to join this conference by calling the conference host must enter the PIN code.

Here is how to use PIN code to lock the conference call:

1. During the call, in the GVC3220 display LCD call screen Click the Menu bottom then .
2. Enter the PIN Code to lock the conference call. If it is empty, the conference call is not locked. Click on OK to confirm.



Figure 70: Enter PIN Code to Lock Conference

3. Now the conference call is locked. If someone wants to join the conference call by calling this GVC3220, the same PIN code will be required to be entered before the call goes through.

Here is an example on how to use PIN code to enter the locked conference call:

1. Make a video call to the GVC3220 that has locks the conference call from another GVC3220.



2. The GVC3220 caller will show a video windows with voice prompt asking for PIN code.

3. On the GVC3220 caller's call screen Menu  → Dial DTMF . Then input the DTMF with PIN code followed by #.

4. The GVC3220 caller joins the conference call after entering correct PIN code in DTMF.

FECC - Camera Control in Conference

During the video call, if the local party (GVC3220) and remote party support FECC, the remote camera can be controlled on the GVC3220.

Here is how to use FECC on the GVC3220 to control remote party's camera:

1. Make sure the GVC3220 and the remote party support FECC and it is enabled on both parties. For GVC3220, FECC setting is under web UI → **Account** → **SIP/Bluejeans/Zoom** → **Codec Settings**: "Enable FECC". If the remote party is another vendor's video device, please check the documentation from the vendor to enable FECC.
2. Establish video call between GVC3220 and the remote party.
3. On the GVC3220 remote control, press the camera button  and the following prompt pops up on GVC3220 display device.




Figure 71: FECC – Remote Camera Control

4. Use UP/DOWN/OK navigation keys on the GVC3220 remote control to select the remote party, e.g., GVC-LAB in the above figure. This will bring up camera control interface.
5. On the GVC3220 remote control, press the navigation keys and zoom in/zoom out buttons to adjust camera.

End Conference

To end the conference, tap on END button  or press key  on GVC3220 remote control to either “Exit Conference” or “End Conference”. If GVC3220 is the conference host:

- Select “Exit conference” so that the GVC host will leave the conference itself while the IPVT conference will still be going on. The GVC host can join back the conference by pressing the remote control's button   in order to continue/end the meeting.

Note: The conference can be ended by WebRTC host or admin through web portal afterwards as well.

- Select “End conference” so that the IPVT conference will be ended and all of the other participants will be disconnected from the IPVT server.

If the conference member hangs up the call, it will be disconnected from the conference, but other parties in the conference will stay in the conference.




Figure 72: End Conference

Power Off During a Conference Call

During the meeting, if the user presses Power ON/OFF button, a new dialog will be prompted that allows user to end the current call and shutdown GVC3220 immediately.




Figure 73: Power Off

Choose “Power off” to end the conference call and power off the GVC3220 immediately or choose “Power off when idle” to shut down the device when the conference call is ended.




Figure 74: Power Off During a Call

Schedule

Schedule feature allows users to set a specific time to host a conference in advance, with conference reminder and members.

Follow one of the ways below to access schedule conference screen:

- On the home screen, click on  “Schedule” button.




Figure 75: GVC3220 Schedule Screen

- Users will see the scheduled conferences (after the current time) in the schedule screen. Select one conference entry to view details.

- User may proceed as follows:
 - Press  to switch between “Invited” and “Mine”, where it shows meetings where the GVC is invited (participant) to and meetings to host.
 - Press  to access google account setting

Note: You will be asked to install GMS App Google Kit first if not available. Which is a collection of Google applications and APIs that help support functionality across the device. The apps are working together seamlessly to ensure the GVC android device provides a great user experience.




Figure 76: GMS Google Kit not installed

View Conference Details

Users could view scheduled conference details after the current time. Select one conference and press "OK" key on GVC3220 remote control to view conference details.

- **If the Conference was already established:** Schedule status is “Over”, the user can then choose to “Delete” or Reschedule the conference.




Figure 77: “Over” Conference Details Screen

- **If the Conference was not established yet:** Schedule status is “Not Start”, the user can then choose “Cancel” to delete it, “Edit” or “Start” the conference.




Figure 78: “Not Start” Conference Details Screen

Add Scheduled Conference

Follow the steps below to add a scheduled conference:

- On the home screen, select  to access schedule screen.
- On GVC3220 remote control, press the  shortcut key to create a new conference.




Figure 79: GVC3220 Add Meeting Screen

- Fill in conference name, members, start time, conference duration and etc.
- Press the yellow shortcut key on the remote control to save the scheduled conference.

Table 12: GVC3220 Add Conference Parameters

Parameters	Descriptions
Subject	It is used to set the conference name to identify this conference.
Start Time	It is used to configure the start time of the conference.
Duration	It is used to configure how long the conference is supposed to last.
Preset	It is used to select a camera preset when the scheduled conference starts, the GVC3220's camera will be automatically placed to the preset position. Click on Conference preset and select "Custom" to be redirected to preset setting interface to configure and set a preset. Default is "Not set".

Recurring	<p>Users could select recurring for the scheduled conference, to repeat the conference depending on the chosen option. The recurring options are:</p> <ul style="list-style-type: none"> • No repetition (One-time event) • Daily • Every Weekday (Mon-Fri) • Weekly • Monthly (by week) • Monthly (by day) • Yearly • Custom
Members	<p>Click on  button to access the Add Member screen. Users can add one member or a group of members. Press the yellow key on the remote control to save and go back to schedule screen. Up to 8 members can be added.</p>

Edit Scheduled Conference

Follow the steps below to edit scheduled conference:

1. Access conference schedule screen and select the conference entry users would like to edit.
2. Select the conference and press YELLOW shortcut key from the GVC3220 remote control to access edit screen.
3. Press the yellow shortcut key on the remote control to save changes and go back to schedule screen.




Figure 80: Edit conference

Voicemail

When there is a new voicemail, the voice mail icon  will show up as a notification in the status bar. Users could login the web UI → **Account** → **SIP/IPVideoTalk/H323** → **General Settings** to configure the access number for the voicemail.

Follow the steps below to access voicemail:

1. Access the dial screen and input voicemail access number.
2. Press  on GVC3220 remote control or click on button  on the call screen to dial into the voicemail box.
3. Follow the Interactive Voice Response (IVR) for the message retrieval process.

Voice mail is accessible under **Settings** → **Advanced** → **Voicemail**.




Figure 81: Settings - Voicemail

- The users will be asked to configure the Voicemail Access Number before being able to access:




Figure 82: Voicemail Access Number Prompt

Call Features

The GVC3220 support traditional and advanced telephony features including caller ID, caller ID with caller Name, call waiting, call forward and etc. for the SIP account. Before using the following feature code, please make sure "Enable Call Features" option is set to "Yes" under **web GUI → Account → SIP → Call Settings**. Please note this feature does not apply to IPVideoTalk account or H.323/BlueJeans/Zoom account.

Table 13: GVC3220 Feature Code for SIP Account

*01	<p>Use Preferred Codec (per call).</p> <ul style="list-style-type: none"> • Dial *01 followed by the preferred codec code and the phone number. • The device will use this codec in the INVITE SDP as the first codec when initiating the call. • Codec code: PCMU: 7110 PCMA: 7111 G722: 722 G722.1: 7206 <p>For example, if the user would like to use PCMA as the preferred codec to call phone number 334455, enter *017111334455. Please note the actual codec being used might be different, which is the negotiation result between the endpoints and SIP server.</p>
*02	<p>Force Codec (per call).</p> <ul style="list-style-type: none"> • Dial *02 followed by the preferred codec code and the phone number. • The device will be forced to use this codec during the call. • Codec code: PCMU: 7110 PCMA: 7111 G722: 722 G722.1: 7206 <p>For example, if the user would like to force using PCMA to call phone number 334455, enter *017111334455.</p>
*16	Enable and force SRTP for all subsequent calls.
*17	Disable SRTP for all subsequent calls.
*18	Enable SRTP per call.
*19	Disable SRTP per call.



*30	Block Caller ID (for all subsequent calls). <ul style="list-style-type: none"> Dial *30.
*31	Send Caller ID (for all subsequent calls). <ul style="list-style-type: none"> Dial *31.
*50	Disable Call Waiting. <ul style="list-style-type: none"> Dial *50.
*51	Enable Call Waiting. <ul style="list-style-type: none"> Dial *51.
*67	Block Caller ID (per call). <ul style="list-style-type: none"> Dial *67 followed by the phone number.
*82	Send Caller ID (per call). <ul style="list-style-type: none"> Dial *82 followed by the phone number.
*70	Disable Call Waiting (per Call). <ul style="list-style-type: none"> Dial *70 followed by the phone number.
*71	Enable Call Waiting (per Call). <ul style="list-style-type: none"> Dial *71 followed by the phone number.
*72	Unconditional Call Forward. To set up unconditional call forward: <ul style="list-style-type: none"> Dial *72 followed by the phone number to forward the call.
*73	Cancel Unconditional Call Forward. To cancel the unconditional call forward: <ul style="list-style-type: none"> Dial *73.
*74	Paging Call. <ul style="list-style-type: none"> Dial *74 followed by the phone number to send the paging call.
*83	Force Audio Calling (per call). <ul style="list-style-type: none"> Dial *83 followed by the phone number to send the audio call.
*84	Force Video Calling (per call). <ul style="list-style-type: none"> Dial *84 followed by the phone number to send the video call.
*90	Busy Call Forward. To set up busy call forward: <ul style="list-style-type: none"> Dial *90 followed by the phone number to forward the call.
*91	Cancel Busy Call Forward. To cancel the “busy call forward”: <ul style="list-style-type: none"> Dial *91.
*92	Enable Call Forward No Answer. To set up Call Forward No Answer: <ul style="list-style-type: none"> Dial *92 followed by the number to forward the call. The default timeout before the call is forwarded is 20 seconds.
*93	Cancel Call Forward No Answer. To cancel Call, Forward No Answer: <ul style="list-style-type: none"> Dial *93.



ADDITIONAL FUNCTIONS

Bluetooth

On GVC3220, Bluetooth is enabled by default. Users could connect Bluetooth by remote control, send or receive files to cellphone, or use Bluetooth speaker and etc. on GVC3220.




Figure 83: Basic Settings - Bluetooth




Figure 84: Bluetooth Settings

Notes:

- Press  to Cancel the Bluetooth connection
- Press  to allow the GVC3220 to be visible for other Bluetooth devices. Confirm by pressing OK on the pop window:




Figure 85: GVC3220 Bluetooth – Open Discovery

Using Bluetooth Remote Control

Users could use GVC3220 Bluetooth remote control that comes with the GVC3220 packaging to control and configure a GVC3220. When the GVC3220 boots up for the first time, a setup wizard will guide the users to pair and connect the remote control to the GVC3220. Or you can refer to the steps below:

1. Open the battery cover on the back of the remote control. Place four AAA batteries properly and put the cover back on, the remote control can be used normally. At this time, the remote control is in infrared mode, and the LED light of the remote control shows green color when used.
2. You can also choose to pair the remote control with GVC3220 main case according to the interface prompts: Please align the remote control to the device, long press OK and 5 on the remote control to connect to the GVC, when the LED on the top of the remote control flashes, the keys can be released. At this time, the remote control will be automatically paired and connected, and the LED light of the remote control shows blue color when used.

Notes:

- Users can also download GVC3220 Bluetooth remote control app for Android™ and install to your Android™ device. This app can be used as an alternative for the remote control in the GVC3220 package.
- After the remote control is paired, users could follow the setup wizard to initiate GVC3220 step-by-step, or skip the setup wizard.

Using Bluetooth Headset

Once the Bluetooth headset is connected with GVC3220, it will automatically use Bluetooth headset for calls.




Figure 86: Connecting a Bluetooth Headset

GVC Remote Client Application

Besides using GVC3220 Bluetooth remote control in the package, users could also download the Grandstream GVC Remote Client application, and install it on an Android device. GVC3220 remote control application is used via Bluetooth protocol. Follow the steps below to install the remote control application:

1. Please go to GVC3220 LCD menu → **Settings** → **Status** → **Remote control** to send GVC Remote apk to Bluetooth device or scan the QR code.




Figure 87: Status - Remote control




Figure 88: Remote Control Settings

2. Once GVC Remote app is installed on your Android device, open it and access settings screen.
3. Select the GVC3220 device that users would like to connect to. Each discovered GVC3220 could be distinguished by the last 6 digits of its MAC address.
4. Pair GVC Remote app with GVC3220 via Bluetooth. Users might see prompt on GVC3220, and Android device to confirm the passcode during pairing and connection process.
5. After pairing and connecting the remote control application, users can use the keys and options on the Android device touch screen to control GVC3220.




Figure 89: GVC3220 Remote Control Application on Android Device

- Tap on button  at the upper right corner to access settings screen as the left figure shows above.
- Tap on button  to go back to home screen as the figure in the middle shows above.
- Tap on button  to bring up navigation panel and digital keyboard as the right figure shows above, tap on  again to hide the keyboard.

Note: Users can Send the GVC Remote apk using Bluetooth feature:




Figure 90: Send the GVC Remote apk using Bluetooth

- User can also use QR code to acquire the “GVC Remote” App:



Figure 91: QR Code for Remote Control App

For more information about how to use GVC remote apk on your Android device, please refer to the GVC3220 remote control client quick start guide below:

http://www.grandstream.com/sites/default/files/Resources/GVC3220_Remote_Control_Client_Quick_Start_Guide.pdf

Power Manager

Timeout Operation: Choose either to put the GVC3220 in Sleep Mode or to shut it down.




Figure 92: Timeout Operation

Timeout Time: Select the interval before the device enters sleep mode or shutdown. The available intervals are 1 minute, 5 minutes, 10 minutes, 15 minutes, 30 minutes and 60 minutes. The default setting is "Never".




Figure 93: Timeout Time

Screensaver Timeout: Set the screensaver timeout for the GVC to enter screensaver mode. The default value is 5 minutes. Options are: Never, after 1, 3, 5 or 10 minutes.




Figure 94: Screensaver Timeout

APPLICATIONS

GVC3220 provides built-in applications such as Call History, File Manager, Recorder, etc. Users could also download the apps from GS market to install on GVC3220.




Figure 95: GVC3220 Applications

LDAP contacts

LDAP contacts application can be accessed in GVC3220 display device LCD → **Applications** → **LDAP Contacts**. It helps users to access and manage the contacts at ease.




Figure 96: Applications - LDAP contacts

Here is the main interface of LDAP contacts:



Figure 97: LDAP Contacts Interface

- Press  to Add the selected LDAP contact to the local phonebook
- Press  for Batch Add, the below screen will show up:





Figure 98: LDAP contacts - Batch Add

- Press  for LDAP parameters:




Figure 99: LDAP contacts - Settings

LDAP Settings

Before starting using LDAP on GVC3220, the users must configure the LDAP settings first. Press


 shortcut key on the GVC3220 remote control to access LDAP settings, or the users can configure it under GVC3220 Web UI → **App** → **LDAP** page.

Table 14: GVC3220 LDAP Settings Parameters


Connection Mode	It is used to select which protocol will be used for LDAP searching, LDAP or LDAPS.
Server Address	It is used to configure the URI of the LDAP (Lightweight Directory Access Protocol) server.
Port	It is used to configure the LDAP server port. The default LDAP port number is 389.
Base DN	It is used to configure the LDAP search base. This is the location in the directory where the search is requested to begin. Example: dc=grandstream, dc=com ou=Boston, dc=grandstream, dc=com
Username	It is used to configure the bind "Username" for querying LDAP servers. Some LDAP servers allow anonymous binds in which case the setting can be left blank.

Password	It is used to configure the bind "Password" for querying LDAP servers. The field can be left blank if the LDAP server allows anonymous binds.
LDAP Name Attributes	It is used to configure the "name" attributes of each record which are returned in the LDAP search result. This field allows the users to configure multiple space separated name attributes. Example: gn cn sn description
LDAP Number Attributes	It is used to configure the "number" attributes of each record which are returned in the LDAP search result. This field allows the users to configure multiple space separated number attributes. Example: telephoneNumber telephoneNumber Mobile
LDAP Mail Attributes	It is used to configure the "mail" attributes of each record which are returned in the LDAP search result. Example: Mail
LDAP Name Filter	It is used to configure the filter used for name lookups. Examples: ((cn=%)(sn=%)) returns all records which has the "cn" or "sn" field starting with the entered prefix; (!(sn=%)) returns all the records which do not have the "sn" field starting with the entered prefix; (&(cn=%) (telephoneNumber=*)) returns all the records with the "cn" field starting with the entered prefix and "telephoneNumber" field set.
LDAP Number Filter	It is used to configure the filter used for number lookups. Examples: ((telephoneNumber=%)(Mobile=%) returns all records which has the "telephoneNumber" or "Mobile" field starting with the entered prefix; (&(telephoneNumber=%) (cn=*)) returns all the records with the "telephoneNumber" field starting with the entered prefix and "cn" field set.
LDAP Mail Filter	It is used to configure the filter used for mail lookups. Example: (mail=%)
LDAP Displaying Name Attributes	It is used to configure the entry information to be shown on phone's LCD. Up to 3 fields can be displayed. Example: %cn %sn %telephoneNumber



Max Hits	It is used to configure the maximum number of results to be returned by the LDAP server. If set to 0, server will return all search results. The default setting is 50.
Search Timeout (ms)	It is used to configure the interval (in milliseconds) for the server to process the request and client waits for server to return. The default setting is 30.
LDAP Lookup When Dialing	It is used to set if allow the phone system to do the LDAP number searching when making outgoing calls. The default setting is "No".
Search LDAP For Incoming Call	It is used to set if allow the phone system to do LDAP number searching for incoming calls. The default setting is "No".

Here is an example configuration on GVC3220 LDAP settings in web UI. The LDAP server is the built-in LDAP server in Grandstream UCM6xxx:



The screenshot shows the LDAP configuration interface with the following settings:

- Connection Mode: LDAP
- Server Address: 192.168.5.140/
- Port Number: 389
- Base Dn: ou=pbx,dc=pbx,dc=com
- User Name(Binding DN):
- Password:
- Ldap Name Attributes: CallerIDName
- Ldap Number Attributes: AccountNumber
- Ldap Mail Attributes:
- Ldap Name Filter: (CallerIDName=%)
- Ldap Number Filter: (AccountNumber=%)
- Ldap Mail Filter:
- Ldap Displaying Name Attributes: AccountNumber CallerIDName
- Max Hits: 50
- Search Timeout (s): 30
- Ldap Lookup When Dialing:
- Search Ldap For Incoming Call:

Figure 100: LDAP Settings Example in Web UI

Call History

Call History provides users access to phone's recent call records. Users can view all records, or select different categories for incoming calls, outgoing calls, missed call and conference.

To access Call History,

1. go to Home screen → **Applications** → **Call History**



Figure 101: GVC3220 Call History Screen

2. Click on a record in the call history and press  to dial out this number directly. Press "OK" key on GVC3220 remote control to view call details for this number.



Figure 102: GVC3220 Call History Details

3. Users can choose to **"Batch remove"** history logs, show the log **"Details"** or **"Reschedule"** the call/conference

Note: Call history displays all conference call histories as well. Press "OK" key or  to dial out directly, and there is no need to input the password again. However, if the conference does not exist or the password has been changed, the re-dial will fail.

Add Contact from Call History

1. Access Call History screen and Press the yellow shortcut key to bring up the details screen.
2. Press again the yellow shortcut to “Add” to contacts
3. Select to add as new or existing contact.




Figure 103: GVC3220 Add Contact Screen

4. Select existing contact or press the blue shortcut key on GVC3220 remote control to access edit screen.
5. Fill in contact information and press the yellow shortcut key on the remote control to save the contact.

File Manager

File Manager allows users to delete, move, copy, paste, send, rename files (including files on storage device such as USB flash drive and SD card), and query file properties on GVC3220.

Browse Files

1. Insert USB/SD storage device into USB port on GVC3220. It will take a few seconds for GVC3220 to prepare the connection.
2. The USB storage icon will show up on the status bar.
3. Go to Home screen → **Applications** → **File Manager**.





Figure 104: Applications - File Manager

4. Open the target folder:
 - **All:** Internal storage and Storage devices (USB or SD Card)
 - **Image:** image files and screenshot
 - **Audio:** audio files only
 - **Video:** video files only
 - **Backups:** Saved backups
 - **Downloads:** Saved download files



Figure 105: File Manager Folders

5. Press  shortcut key to search for a file.




Figure 106: File Manger - Search

6. Press  shortcut key for properties

File Operations

1. Go to Home screen → **Applications** → **File Manager**.
2. Open the target folder and select the file.
3. Possible File operations are available on the bottom panel




Figure 107: File Operations Panel

- Press the red shortcut key to “Delete” the selected file
- Press the yellow shortcut key to “Copy” the selected file
- Press the blue shortcut key to “Edit” the selected file, it provides “Select all” option to batch Delete/Copy files.
- Press  to show the operation panel :
 - Click  “Back” to bring the previous screen
 - Click  to send the file via Bluetooth or other 3rd party applications such as MS Teams:




Figure 108: File Manager - Share File



- o Click  to “Rename” the file:




Figure 109: File Manager - Rename File

- o Click  to show the file “Properties:




Figure 110: File Manager - Properties

- o Click  to search file:




Figure 111: File Manager - Search

- o Click  to create a new folder: A popup will appear to name the new folder




Figure 112: File Manager - New Folder

- Click  to sort files: A popup will appear to allow choosing the Sort option




Figure 113: File Manager - Sort

- Click  to change the display mode between icon or list.



Figure 114: File Manager - List/Icon View

Recorder

The GVC3220 Recorder Application is used for the storage of call recording files for both video and audio conferencing. Users can play, export, lock/unlock, send, rename, or delete these recordings and etc.



Figure 115: Applications - Recorder

The recording screen is as shown below:



Figure 116: GVC3220 Recording Screen

Notes:

- Recording files can be saved to an external SD card, USB flash drive, FTP server or NAS extended storage.
- The locked files cannot be deleted or overwritten, and cannot be shown in the third-party application, but can be viewed in GVC3220 Recorder application.
- When the recording size exceeds 1.9G, the GVC3220 will create a new file automatically to continue recording. There will be a prompt to indicate the storage space is insufficient if the disk storage is full.

- Users can access Video Settings by clicking  →  :




Figure 117: Recorder App - Video Settings

Setup Wizard

GVC3220 offers a Setup Wizard tool to guide users into configuring their units step by step, the setup wizard appears automatically at factory reset, or it can be accessed anytime from LCD **menu** → **Applications** → **Setup Wizard**.



Figure 118: Setup Wizard

Users can follow the steps using the remote control to setup fields, skip, return, or confirm the action. Setup wizard tool is useful to lead users to check and configure the GVC3220 settings such as language, accounts, interface status and etc.





Figure 119: Setup Wizard – start

- Choose Language and Time Zone Then, click  to proceed.
- The following step is “Remote Control Pairing”:
 - Follow the displayed steps to properly pair your remote-control device
- Configuration Mode: Users can choose to either complete the configuration through the wizard or through the mobile App.




Figure 120: Setup Wizard - Configuration Mode

- After pressing  the GVC3220 Setup Wizard will initiate.
1. Detect active GVC3220 ports:
 - This allows users to make sure that all the connected interfaces are working properly.




Figure 121: Setup Wizard - Interface Detection

2. Network Configuration:
 - Ethernet: Set DHCP or a Static IP




Figure 122: Setup Wizard – Ethernet

- Fill in the Static IP parameters:



Figure 123: Setup Wizard - Static IP

- Press the Yellow shortcut key to connect a Wi-Fi Network:




Figure 124: Setup Wizard - Wi-Fi scan

3. Launch GMD wireless microphone pairing process:



Figure 125: Setup Wizard - GMD

4. SIP Account configuration:




Figure 126: Setup Wizard - Account

5. Remote Control Description:




Figure 127: Setup Wizard - Remote Control

- Click “More” for advanced options: Users can check the hardware/software version, upgrade firmware or download “GVC Remote” apk ...






Figure 128: Setup Wizard - Remote Control Settings

6. Introduction to IPVideoTalk Service:



Figure 129: Setup Wizard – IPVideoTalk

7. Completing the Setup Wizard:






Figure 130: Setup Wizard – End

- Click “Done” to finish the Setup Wizard and start using the GVC3220.

Backup

Backup Data

GVC3220 BACKUP application is used to back up data or import backup files to restore data. It can be accessed from Home screen → **Applications** → **File Manager** → **Backups**




Figure 131: File Manager - Backups



GVC3220 supports manual backup and automatic backup:

- Press the yellow shortcut key on the remote control to create new backup manually. The user will select preferred backup data and press the yellow shortcut key again to start backup.



Figure 132: New Backup

- Press the blue shortcut key on the remote control to enable and configure automatic backup Settings:




Figure 133: GVC3220 Automatic Backup Screen

Note: Insert SD card or USB flash drive to the GVC3220 before configuring backup path/address.

Restore Backup Data

Select one backup data and press "OK" key to access restore screen, select the preferred data, and press the yellow shortcut key to start the restore process:



Figure 134: GVC3220 Restore Backup Data Screen

State Detection

When troubleshooting GVC3220, users could go to GVC3220 home screen → **Applications** → **State Detection**




Figure 135: Applications – State Detection

Then, users can have access to the below information:

- **Interface Detection:** To verify that all the connected interfaces are working properly.
- **Network Detection:** To make sure that the active Network Interfaces are connected
- **Account Detection:** To double check the account registration status
- **Audio Detection:** Users can perform an Audio loopback test to verify if the Audio Output device is working fine. (Follow the displayed instructions to record audio input then play it back)



Figure 136: Interface Detection




Figure 137: Network/Account Detection




Figure 138: Audio Detection.

Move App to SD Card

The apps that are not built-in on GVC3220 can be moved to an external SD card plugged to the GVC3220 from GVC3220 LCD → **Settings** → **System** → **Apps** page.

- Users could check the apps list on the external SD card by pressing OK on the Remote Control:





Figure 139: System - Apps

Notes:

- Press  to show Blocked Applications,
- Press  to display the allowed Applications
- Press  for Reset app preferences:




Figure 140: Reset app preferences

Uninstall Application

The applications (except the system applications) on GVC3220 can be uninstalled. Go to **LCD Home screen** → **Applications**, click on YELLOW shortcut key to enter the "Uninstall Mode".

- Users will see the apps that can be deleted shown with  icon. Select and confirm the uninstallation:




Figure 141: Delete App

- Once done, press the yellow shortcut key on the remote control to go back to normal mode.

GS MARKET

GVC3220 provides access to apps directly via built-in GS market. Users could download the apps from the market and install to GVC3220.

View Apps

On GVC3220 Home screen, click on **Applications** → **GS Market** Users could view the apps by category:




Figure 142: GVC3220 GS Market

Notes:

- Press  to show the download history,
- Press  to display available/installed APPs
- Press  to start/stop installing the selected App.
- GS Market provides pre-downloaded proprietary application versions that are guaranteed to work best with the GVC3220: Chrome, GMS, Google Play, Zoom and Teams.
- Users need to deploy/install GMS in order to use Google Play and other Google services properly.
 - Click on GMS to install the whole kit in one click:




Figure 143: GMS Installation

Update Apps

GVC3220 will detect to update automatically if there is new version available for the installed apps when the network connection is normal. Users can view the relevant information, and update apps on the “Installed” screen.

IPVIDEOTALK

The GVC3220 has a built-in IPVideoTalk account (active by default). The IPVideoTalk application provides an interface for the user to manage this service on the GVC3220, e.g., view enterprise directory contacts, check and reply to notices from IPVideoTalk server as well as change IPVideoTalk settings. The user can access IPVideoTalk application from LCD → **Applications** → **IPVideoTalk**.






Figure 144: GVC3220 IPVideoTalk Application

Instant Meetings



Users can start an instant meeting just by selecting **Instant meetings** to display IPVideoTalk Call Screen. Once it is done, the user will be the host of this instant conference and will be able to add more participants and manage everything about the conference.

Meeting List



Users can view all the scheduled meetings by selecting **Meeting list**, this will take the user to the meetings list page where all the scheduled conferences are listed.

Call



Users can select **Call** in order to directly go to the dial page.

IPVideoTalk Contacts



The contacts are managed centrally in the server side. Users can access by selecting **Contacts**. This will show the Enterprise Contacts screen.




Figure 145: IPVideoTalk - Contacts

- Select an entry in the directory and press the Green Call button  on the GVC3220 remote control to call this contact.
- Press the red shortcut key on the GVC3220 remote control to refresh the directory.
- Press the yellow shortcut key on the GVC3220 remote control to search contacts in the directory.
- Press the blue shortcut key on the GVC3220 remote control to select entries and make a batch call to multiple contacts in the directory.

Notices

In the IPVideoTalk application, any incoming messages from the server side will be displayed in **“Notices”**. In the following figure, “4” indicates the number of new/unread messages.




Figure 146: IPVideoTalk - Notices

- Click on “Notices” to access the messages. Use the navigations keys/OK keys on the GVC3220 remote control to select and read the messages.




Figure 147: Notices - Messages

- Press the blue shortcut key on the remote control to show details:




Figure 148: Notices - Details

Settings



In the IPVideoTalk application, click on  to configure “Account Active” and “Display Name” for the IPVideoTalk account on GVC3220. The user can also enter the IP address of his IPVideoTalk Server, or restore it to the default, then click on “Save” to link the GVC3220 unit with the IPVideoTalk Server configured. Current IPVideoTalk version information will be shown under “Application Information”.





Figure 149: IPVideoTalk Account Settings

Notes:

- Press  to Cancel modification
- Press  to keep changes
- Press  for default account configuration.
- Users can check the current IPVideoTalk Plan as well used on the GVC3220 and its expiration date.

Please, refer to the following figure:




Figure 150: Current Plan used and its expiration time

Join an IPVideoTalk Meeting

Users can join an IPVideoTalk meeting by dialing the host GVC3220's IPVideoTalk ID or meeting ID. Please note only after meeting starts, GVC3220 can use this method to join the conference as a participant.

1. Access the dialing page and Dial the meeting ID or the IPVideoTalk ID to join an active meeting.




Figure 151: IPVideoTalk Dialing Page

Busy Tone Responses

The GVC3220 can only join one IPVideoTalk meeting at a time. A specific busy response message will be displayed rather than SIP 486 busy error prompt on IPVideoTalk dialing interface when users try to invite a busy unit.

- If the GVC is already hosting a meeting, it cannot be added as a participant of another IPVideoTalk meeting.
- If the GVC is already a participant in an active IPVideoTalk meeting, it cannot be added to another meeting.

Manually Start IPVideoTalk Tip

If a meeting is scheduled from IPVideoTalk Web Portal, then the meeting will sync to host GVC3220 device LCD → Schedule interface. There will be a prompt message “Manually start the meeting will need to re-schedule, please confirm” when pressing “**CALL**” button on remote to start the meeting manually before or after scheduled time.






Figure 152: Manually start Scheduled Meeting

Note: The host and invitees of webinar receive a reminder prompt for preparation to host/join the meeting before its start.

For more information about your IPVideoTalk services, settings, how to manage accounts and schedule meetings, please check IPVideoTalk user manual from <http://www.ipvideotalk.com>

Conference Control

IPVideoTalk Meeting Operations

If GVC3220 joins an IPVideoTalk meeting as a participant and the host is any WebRTC client, the participant could click on button  from conference control screen to raise hand and attract host attention to indicate that he/she wants to be unmuted or needs any help.

The raised hand status of GVC3220 participants could be checked from Participants List on Host WebRTC

Client, as shown in below figure




Figure 153: Participants list

- The WebRTC host can proceed as follows.

- Force hand down by clicking on button .
- Enable or disable participants video/audio feed using the available camera and mic icons.

- The host GVC3220 can do the below operations:

- Lower hand of a participant:




Figure 154: Lower hand of one participant

- Lower hand of all participants: The host can go to “Conf Control” and click on more options (Next to Me) to bring the hand icon.

-  Mute/Unmute
-  Enable/Disable participants' camera

Start Cloud Recording

During an IPVideoTalk meeting/webinar, under Call Screen of host GVC the users can control cloud recording.

- To start/stop cloud recording, users could click on “Record” button under host GVC3220 LCD → Call screen, or press */* shortcut key on remote control to **Open/Close** server recording :




Figure 155 : Server Recording

- There will be an icon  shown on the left upper corner of host GVC as well as all other participants to indicate the server recording is in progress
- Users could log in to IPVideoTalk Enterprise web portal → Recordings page to View/Download/Delete the recordings for the cloud meetings/webinars:

Subject	Meeting ID	Organizer	Schedule Email	Start Time	Files
<input type="checkbox"/> IPVideoTalk Meeting	52696990	8200443 -IPVideoTalk Small...	namang@grandstar...	07/17/2017 07:4...	Download Delete

Figure 156 : IPVideoTalk Recordings

Note: There are some prerequisites to enable cloud recording features on GVC3220. The subscribed IPVideoTalk plan should include cloud recording support and adequate cloud storage space for recording. Please refer to IPVideoTalk website or User Manual for the latest plan information.



GVC3220 WEB UI FEATURES

GVC3220 embedded Web server responds to HTTP/HTTPS GET/POST requests. Embedded HTML pages allow users to configure the application device through a Web browser such as Mozilla Firefox, Google Chrome etc.

Accessing GVC3220 Web GUI

The IP address of the GVC3220 is displayed on top left of display device.



Figure 157: IP Address from the display device

To access GVC3220 Web GUI:

1. Ensure your GVC3220 is properly powered up and connected to the Internet.
2. The IP address of the GVC3220 will show on the top status bar of the connected display device (e.g., TV) via HDMI.
3. Type the IP address in your PC's browser (see figure below).
4. Enter username and password to login. (The default administrator username is "admin" and the default random password can be found at the back sticker on the GVC3220).





Figure 158: GVC3220 Web GUI - Login



Share Screen (without login)

Starting firmware 1.0.1.35, “Share Screen” is available on the web UI without login.

1. Click on “Share Screen”



2. A prompt will ask to enter the code and press “Turn on Sharing”.




Figure 159: Share Screen – Enter the code

The code is automatically generated and will displayed on the connected TV.




Figure 160: Share Screen Code

3. Select the screen to share and press “Share” button.





Figure 161: Share Screen – Select the screen to share

Saving Changes

When changing any setting on GVC3220 web UI, users need to submit them by pressing the



button on the bottom of the page, and then, click the



button on the top

of the page to apply the configuration changes.

Note: For those options with  next to it on the Web page, users have to reboot GVC3220 to take effect.




Figure 162: Reboot is mandatory

Definitions

This section describes the 6 options on GVC3220 Web GUI. Please view Settings, Maintenance and Status specifications in Administration Guide.

- **Call:** Users could start video conference and control conference from Web GUI.
- **Account:** SIP, IPVideoTalk, H.323, Bluejeans and Zoom account configuration
- **Call features:** Audio/Video call settings
- **Network Settings:** Ethernet, Wi-Fi, OpenVPN ...
- **System Settings:** Power, Date&Time, Language ...
- **Device Control:** Video Control ...
- **App:** LDAP, Broadsoft, 3rd party Apps ...
- **Maintenance:** Upgrade, Troubleshooting, Reboot ...
- **Status:** Account Status, Peripheral Status, Network Status, System Info and Remote Control

Users can log in as an administrator or a normal user. The following table shows the web pages accessible by normal user and administrator. It is recommended to change the default password for user and administrator after login for the first time.

Table 15: GVC3220 Web Access

User Type	Username	Default Password	Accessible Web Pages
Normal User	user	123	<ul style="list-style-type: none"> • Call • Call features • Network Settings • System Settings • Device Control • App • Maintenance • Status Note: Limited Options.
Administrator	admin	A random string that can be found on the MAC Tag in the back of the GVC3220	All pages



Toolbar

The web UI tool bar is on the upper right corner of the web UI page.




Figure 163: GVC3220 Web UI Tool Bar

- **Search button**  : User can search Web GUI options by clicking the button to display a search bar.
- **DND**: It is used to turn on/off DND mode. Once it is enabled, the DND text will turn into red and all incoming calls will be rejected.
- **Share screen: (HTTPS required)** Users need to switch the web interface to HTTPS before using this function. It allows to share the screen directly from web interface.
- **Remote Control**: Click to bring up virtual remote control panel.
- **English**: Select the display language for the web UI.
- **Admin**: Log out from the web UI.

Call Page

GVC3220 Web UI call page is shown below. Users could make calls and initiate conference from Web UI.



Recent call			
	108539	IPVideoTalk	Yesterday  
	Amelia	SIP	4000  
	Liam	SIP	3000  
	Olivia	SIP	2000  
	William	SIP	1000  

Figure 164: GVC3220 Web UI - Call

Contacts Page

This page lists Contacts, Schedule, and Call History.

Web GUI Contacts

Users could search/add/delete/edit contacts on web page. The operations will be synchronized and can be viewed from LCD as well. The web UI contacts page is as shown below.





Figure 165: GVC3220 Web UI - Contacts

5. Click on  next to the contact to dial the contact.
6. Click on  to open more options such as export, import and download contact:
 - Select "Import", "Export" or "Download" options and users will find a pop screen with needed configuration. Refer to the Admin guide for more details.
7. Click on  to popover Add Contact screen. Fill in contact information and save.
8. Click on  and users will find Edit Contact screen on the right. Edit contact information and save.
9. Click on the checkbox for "Delete" and users can select the contacts to delete from GVC3220.

Groups

GVC3220 supports up to 5-way video conference. If there are more than 4 conference members, only the first 4 members in the group will be dialed.







Figure 166: GVC3220 Web UI - Groups

10. Click on  next to the group to call the contacts in the group.
11. Click on  and users will find Add Group screen on the right. Select group members from existing contacts and save.
12. Click on  and users will find Edit Group screen on the right. Edit Group information and save.
13. Click on the checkbox for “Delete” and users can select the groups to delete from GVC3220.

Schedule

Conference can be scheduled, edited, and deleted from web UI. See figure below. Please refer to chapter **Schedule** for more details for each option.





Figure 167: GVC3220 Web Page - Schedule

14. Click on  to popover Add Schedule screen. Click on “Save” after configuring the schedule.
15. Move the cursor to the scheduled conference where the scheduled time is displayed,



- The button  will appear for the user to dial out immediately.
- Click  for the Edit Schedule screen.
- Click  to delete the scheduled meeting.

Call History

From web UI, users could also access Call history, which is synchronized with the call history from LCD.





Figure 168: GVC3220 Web UI - Call History

The call history details will be displayed upon selecting an entry. Users can move the cursor to the call history time to re-schedule the call by clicking on , dial out immediately by clicking on , or click  to save in contacts. Also,  to delete all the logs.

Device Control Page

Users could add preset and manipulate PTZ control on this section.

- **Preset Control:** Move the cursor to one preset zone then click to Edit.




Figure 169: Web GUI - Preset Control

- **Camera Control:** Use the available Mode button and direction keys to configurations the camera position accordingly.




Figure 170: GVC3220 Web UI - Camera Control

FACTORY RESET

Users could reset GVC3220 to factory settings via the following ways: Reset via local GUI, via Web page, via the reset hole on the back panel of GVC3220. Factory reset will delete configuration info and syslog info.



Warning: Factory reset will erase all GVC3220 configuration information. Please back up all settings or print useful information before making the following operations. If users lose all parameters or records, Grandstream will not take responsibility for the damage or loss.

Reset via LCD

Go to GVC3220 LCD idle screen → **Settings** → **Factory Reset**, click on the "Reset" button to bring up the prompt box as shown below. Click "OK" to reboot the device and restore factory settings.




Figure 171: Factory Reset via LCD

Reset via Web UI

1. Log in GVC3220 Web UI → **Advanced Settings** → **Upgrade**, the "Factory Reset" option is on the bottom of the page.



Figure 172: GVC3220 Web UI - Factory Reset

2. Click the "Reset" button to bring up the prompt box as shown below. Click "OK" to reboot the device and restore factory settings.






Figure 173: GVC3220 Web UI - Factory Reset Confirmation

Reset via Reset Hole

There is a Reset hole on the back panel of GVC3220, use a small pin to hold against the Reset hole for more than 10 seconds to restore factory settings.

EXPERIENCING GVC3220

Please visit our website: <http://www.grandstream.com> to receive the most up-to-date updates on firmware releases, additional features, FAQs, documentation and news on new products.

We encourage you to browse our [product related documentation](#), [FAQs](#) and [User and Developer Forum](#) for answers to your general questions. If you have purchased our products through a Grandstream Certified Partner or Reseller, please contact them directly for immediate support.

Our technical support staff is trained and ready to answer all of your questions. Contact a technical support member or [submit a trouble ticket online](#) to receive in-depth support.

Thank you again for purchasing Grandstream Video Conferencing System, it will be sure to bring convenience and color to both your business and personal life.

* Android is a trademark of Google LLC.

HDMI[™] HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

